


TONEWORKS

AX1000G

MODELING SIGNAL PROCESSOR



REMS

OWNER'S MANUAL

KORG

Contents

- 1. Introduction ----- 3
 - Main features ----- 3
 - Printing conventions in this manual ----- 3
 - Important things to learn ----- 4
 - Front and rear panel ----- 4
 - The modes of the AX1000G ----- 7
- 2. Playing the AX1000G ----- 8
 - Example connections ----- 8
 - Play mode ----- 8
 - Adjusting the master level ----- 8
 - Adjusting the input level ----- 8
 - Selecting a program ----- 8
 - Bypass and mute ----- 9
 - Auto tuner ----- 9
 - Metronome ----- 9
 - Expression pedal ----- 9
 - Individual mode ----- 10
 - Phrase Trainer mode ----- 11
- 3. Editing ----- 12
 - Editing an effects ----- 12
 - Quick Editing for the DRIVE-AMP effect block ----- 12
 - Setting the noise reduction and program levels ----- 13
 - Modifying the program names ----- 13
 - Writing a programs ----- 13
- 4. Appendices ----- 14
 - Adjusting the expression pedal ---- 14
 - Restoring the user programs to the factory settings ----- 14
 - Troubleshooting ----- 15
 - Main specifications ----- 15
 - Effect parameters ----- 16
 - DRIVE-AMP effects block ----- 16
 - CABINET effect block ----- 17
 - MODULATION effect block ----- 18
 - PEDAL effect block ----- 20
 - AMBIENCE effect block ----- 22
 - Preset Program Parameter List ----- 23

Precautions

Location

Using the unit in the following locations can result in a malfunction.

- In direct sunlight
- Locations of extreme temperature or humidity
- Excessively dusty or dirty locations
- Locations of excessive vibration

Power supply

Please connect the designated AC adaptor to an AC outlet of the correct voltage. Do not connect it to an AC outlet of voltage other than that for which your unit is intended.

Interference with other electrical devices

This product contains a microcomputer. Radios and televisions placed nearby may experience reception interference. Operate this unit at a suitable distance from radios and televisions.

Handling

To avoid breakage, do not apply excessive force to the switches or controls.

Care

If the exterior becomes dirty, wipe it with a clean, dry cloth. Do not use liquid cleaners such as benzene or thinner, or cleaning compounds or flammable polishes.

Keep this manual

After reading this manual, please keep it for later reference.

Keeping foreign matter out of your equipment

- Never set any container with liquid in it near this equipment. If liquid gets into the equipment, it could cause a breakdown, fire, or electrical shock.
- Be careful not to let metal objects get into the equipment. If something does slip into the equipment, unplug the AC adaptor from the wall outlet. Then contact your nearest Korg dealer or the store where the equipment was purchased.

THE FCC REGULATION WARNING (for U.S.A.)

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Unauthorized changes or modification to this system can void the user's authority to operate this equipment.

CE mark for European Harmonized Standards

CE mark which is attached to our company's products of AC mains operated apparatus until December 31, 1996 means it conforms to EMC Directive (89/336/EEC) and CE mark Directive (93/68/EEC). And, CE mark which is attached after January 1, 1997 means it conforms to EMC Directive (89/336/EEC), CE mark Directive (93/68/EEC) and Low Voltage Directive (73/23/EEC).

Also, CE mark which is attached to our company's products of Battery operated apparatus means it conforms to EMC Directive (89/336/EEC) and CE mark Directive (93/68/EEC).

1. Introduction

Thank you for purchasing the **ToneWorks AX1000G Modeling Signal Processor**.

In order to enjoy your **AX1000G** to the fullest, please read this manual carefully, and use the unit correctly. Please keep this manual for future reference.

Main features

- Korg's **BEMS** modeling technology provides detailed and powerful modeling sounds.
- 56 types of modeling effect variations are built-in, and a maximum of eight types of effect can be used simultaneously.
- Forty preset programs (4 x 10 banks) and forty rewritable user programs (4 x 10 banks) are built-in.
- You can use the expression pedal to control eleven types of pedal effect in realtime.
- In individual mode you can use foot switches to turn each effect on/off independently.
- The Sample & Play function lets you record a phrase that you play (for a maximum of 8 seconds), and then operate the pedal to play back the phrase.
- The Phrase Trainer function lets you record up to 16 seconds of sound from an audio device, and play it back at a slower speed without changing the pitch.
- A metronome is built in for practicing convenience.
- Built in tuner mute function for on stage tuning.
- An AUX IN jack is provided so that you can play along with a connected audio device.
- Use the auto chromatic tuner to tune your instrument when the **AX1000G** is bypassed or muted.
- The LCD (liquid crystal display) features an intuitive visual interface.
- The LCD is backlit for easy visibility even in dark locations.

What is **BEMS**?


BEMS (Resonant structure and Electronic circuit Modeling System) is KORG's proprietary sound modeling technology which precisely reproduces the complex character and nature of both acoustic and electric instruments as well as electronic circuits in real world environments.

BEMS emulates a wide variety of sound generation characteristics including instrument bodies, speakers & cabinets, acoustic fields, microphones, vacuum tubes, transistors, etc.

MODELING AND THE AX1000G

Most of the models in the **AX1000G** closely replicate the sounds produced by classic effects, speaker cabinets and amplifiers. While we have chosen not to include the specific names of the companies and their products, you will quickly recognize them if you are familiar with the originals. If you aren't, you will still thoroughly enjoy the sounds the **AX1000G** produces. In either case, you will be amazed at the quality and variety of effects offered as well as the easy to navigate user interface.

Printing conventions in this manual


 marks a point of caution.

LCD screens printed in this manual are only for purposes of illustration, and may not match the actual display on your **AX1000G**.

Important things to learn



Front and rear panel

Front panel



- ① **Effect select knobs**
These knobs select the effect model used in each effect block.
- ② **Effect block LEDs**
The LED will light for effect blocks that are in use. During editing, the LED of the selected effect block will blink.
- ③ **Effect block select switches**
Press these switches to turn each effect block on/off.
- ④ **Value LEDs**
These LEDs will light to indicate the value knobs that can be used for the selected effect model. From the left, they correspond to value knobs 1—5.
- ⑤ **Value knobs**
When editing, rotate these knobs to modify the value of the parameter assigned to each knob. From the left, these are value knobs 1—5.
When not editing, these knobs control the parameters of the effect that is assigned to the DRIVE-AMP effect block by the selected program. (Refer to p.12, “Quick editing for the DRIVE-AMP effect block.”) In general, this is the most important tone shaping effect in a multi effect set up.
- ⑥ **Program LEDs**
The LED of the currently selected program number will light.
- ⑦ **Program switches**
Use these switches to select a program.
- ⑧ **Bank switch**
Each time this switch is pressed, the bank number will increase by one. The bank number will decrease by one if you simultaneously press the bank switch and program switch 4.
- ⑨ **Expression pedal**
This pedal controls the effect that is selected for the PEDAL effect block.

LCD and control panel



- ① **Name display**
This shows the program name, effect name, or parameter name, as appropriate for each operation.
- ② **Edit icon**
This will light if the selected program has been edited. It will blink if the program is currently being edited.
- ③ **Phrase trainer icon**
This will blink when you are in Phrase Trainer mode.
- ④ **Metronome icon**
This will light when the metronome is on. It will blink while the metronome tempo or level is being adjusted.
- ⑤ **MASTER/VALUE display**
This indicates the master level or parameter values.
- ⑥ **NR-PRG LEVEL switch**
Use this switch to adjust the amount of noise reduction or the level of each program.
- ⑦ **RENAME switch**
Use this switch to modify the name of a program.
- ⑧ **Metronome LED**
This LED will blink in time with the metronome tempo.
- ⑨ **EXIT switch**
From any state, you can press this to return to Play mode.
- ⑩ **WRITE switch**
Use this switch to save an edited program.
- ⑪ **Cursor switches (◀, ▶)**
Use these switches to select the parameter that you wish to edit, or when modifying the name of a program.
- ⑫ **MASTER/VALUE switches (▲, ▼)**
Use these switches to modify the master level or the value of a parameter.
- ⑬ **Pedal LED**
This LED indicates the on/off status of the PEDAL effect, or the recording status when the Sample & Play function is being used.
- ⑭ **Bank number display**
This shows the bank of the selected program. When a user program is selected, the decimal point "." located at the lower right of the bank number will light.

The modes of the AX1000G

The AX1000G has three modes: **Play mode**, **Individual mode**, and **Phrase Trainer mode**.


Play mode is the mode in which you can select a program and play it. You can select from a total of 80 programs that use high-quality effect models: 40 preset programs, and 40 user programs that allow you to freely edit the settings to create your very own sounds. When the power is first turned on, you will always be in this mode.

With the factory settings, the user programs contain the same data as the preset programs.

Individual mode is a mode in which you can use the foot switches (the program switches and pedal switch) to individually turn each effect block on/off as you play. It is not possible to switch programs in this mode. Use Play mode to select a programs.

Phrase Trainer mode is a mode in which you can record a phrase from a CD or MD player connected to the AUX IN jack, and play it back as a loop. You can practice by playing along with the repeating loop. Since you can fix the pitch and slow down the playback speed, this is convenient for learning or practicing phrases that you have difficulty discerning.

 When you enter this mode, the **MODULATION**, **PEDAL**, and **AMBIENCE** effect blocks will automatically be turned off.




In Play mode and Individual mode, you can use the effect select knobs etc. to edit the effects, adjust the noise reduction and program level, and modify the program name etc.

2. Playing the AX1000G

Example connections

⚠ The power must be off when you make connections. Unintentional operation may damage your speaker system, or cause malfunctions.

1. Connect your cables from the OUTPUT jacks of the AX1000G to your guitar amp or mixer etc. If you are using a mono connection, connect the L/MONO jack. In order to take full advantage of the AX1000G's sound, we recommend that you use stereo connections.
 2. If you wish to use headphones, plug them into the PHONES jack.
- ⚠** The output from the OUTPUT jacks will be turned off when headphones are plugged in.
3. Connect your guitar to the INPUT jack.
 4. If you wish to use the AUX IN jack, connect an external audio device to it. Use the controls of the connected device to adjust the volume.
 5. Connect the included AC adapter to the DC 9V jack, and plug the AC adapter into an AC outlet. When you plug it in, the power will come on automatically, and the name display will indicate the program name.
- ⚠** Wrap the AC adapter cable around the cable hook. When removing the cable from the hook, be careful not to pull the cable with excessive force.
6. When you have finished making connections, turn on the power of your guitar amp or mixer etc. Play your guitar to produce sound, and check whether connections have been made correctly. Adjust the master level of the AX1000G and the gain or fader controls of your guitar amp or mixer to set an appropriate volume level.



Play mode

When you turn on the power, the AX1000G will always enter **Play mode**, and will be set to the program and master level setting that were last selected when the power was turned off.

Adjusting master level

The MASTER/VALUE display will show the master level immediately after the power is turned on, a program is selected, and after the EXIT switch is pressed.

When the master level is shown, you can use the MASTER/VALUE switches (▲, ▼) to adjust the master level.

Adjusting input level

By holding down the EXIT switch and pressing the MASTER/VALUE switches, you will be able to adjust the input level so that it will match the output of the connected instrument.

EXIT + ▲ "HI IN": For high-output pickups such as humbucking pickups

EXIT + ▼ "LO IN": For low-output pickups such as single coil pickups

Selecting a program

You can select from 40 preset programs and 40 user programs.



User and preset programs are each organized into ten banks, with four programs in each bank. The currently selected bank is shown by the bank number display, and the program is shown by the program LEDs. When a user program is selected, the decimal point "." located at the lower right of the bank number display will light.



To select a program in the same bank

Press a program switch 1—4 to select the desired program. The program LED of the selected program will light, and the name display will indicate the program name.

To select a program from a different bank

Press the bank switch to select the desired bank. (The bank number display will blink.) The banks will cycle in the order of user banks 0, 1, 2, 3 ...9, preset banks 0, 1, 2, 3...9, user banks 0, 1, 2, 3...

- Each time you press the bank switch, the bank number display will increase by one.
- Each time you simultaneously press the bank switch and program switch 4, the bank number display will decrease by one.

When the desired bank number appears, press a program switch 1—4 to select the desired program. (The bank number display will change from blinking to lit.)

Checking the effect blocks used by a program

Not every program uses all of the effect blocks. When you select a program, the effect block LED of each effect block that is used will light. The LEDs of effect blocks that are unused will be dark.

Bypass and mute

Bypass

If you press and hold the program switch of the currently selected program for 0.5 seconds, all effects will be bypassed. At this time, the program LED will blink, and the name display will indicate "BYPASS" for one second.

To defeat bypass, press the program switch whose LED is blinking, or press any other program switch.

Mute

If you press and hold the program switch of the currently selected program for one second and the sound of your guitar will be muted. At this time, the program LED will blink more rapidly, and the name display will indicate "MUTE" for one second.

To defeat mute, press the program switch whose LED is blinking, or press any other program switch.

Auto tuner

When the AX1000G is in bypass or mute condition, the tuner will operate automatically. If you mute the AX1000G you will be able to tune your instrument without producing sound. This is used for on stage tuning.

1. Tune your guitar approximately so that the desired note name appears in the bank number display. The decimal point "." at the lower right of the bank number display will light to indicate a sharp #.
2. Fine-tune your guitar so that only the center of the five value LED's is lit (or so that only the center of the name display is shown).

Example display

A = A
d. = D#

Tuning discrepancy shown by the value LED's and the name display

	Value LED's					Name display
Pitch is flat	☼	☼	☼	○	○	— — — —
Pitch is sharp	○	○	☼	☼	☼	— — — —
Correct tuning	○	○	☼	○	○	— — — —

Changing the calibration setting


As necessary, you can adjust the calibration (the frequency of the standard A pitch) in the range of 438—445 Hz. (440 Hz is "standard")

When the tuner is operating, use the MASTER/VALUE switches (▲, ▼) to adjust the setting. The calibration setting will appear in the MASTER/VALUE display.

⚠ When the power is turned off, the calibration setting you modify will be lost, and will automatically return to 440 Hz the next time the power is turned on.

Metronome

1. When you simultaneously press the RENAME and EXIT switches, the metronome will start. (The metronome icon will blink.)
2. Use value knob 4 to adjust the tempo (range 40—208: shown in the MASTER/VALUE display).
3. Use value knob 5 to adjust the volume of the metronome sound (range 0—30: shown in the MASTER/VALUE display).
4. While the metronome is operating, simultaneously press the RENAME and EXIT switches to stop the metronome.



If you switch programs or edit while the metronome is operating, it will no longer be possible to adjust the tempo or level. To re-adjust the tempo or level, you must first stop the metronome, and then start it once again.

⚠ When the AX1000G is bypassed or muted, it will not be possible to adjust the tempo or level.

Expression pedal


You can use the expression pedal for realtime control of eleven types of effects in the pedal effect block.


If the program uses an effect in the pedal effect block, the pedal effect block LED will light. For the **Hold Delay**, **Tap Tempo Delay**, and **Sample & Play** pedal effects, the operation is different than for other effects (refer to p.21).


2. Playing the AX1000G

Using the expression pedal as you play

1. In **Play mode**, select a program that uses the expression pedal.
2. Make sure that the pedal LED is lit. If it is not lit, press the expression pedal firmly once to make the pedal LED light (the pedal will be turned on).
3. Operate the expression pedal while playing your guitar. As you raise and lower the pedal, the output sound will change correspondingly.

 If **Volume** is selected in the **PEDAL** effect block, it will not be possible to turn the expression pedal on/off. It will remain on (the pedal LED will be lit).


 The on/off status of the expression pedal is not memorized by each program.

 Do not apply excessive force to the expression pedal. Before operating the expression pedal, verify the amount of force that is required to make the pedal LED light and to apply the effect.

Individual mode

In this mode you can press the program switches or the pedal switch to turn each individual effect block on/off while you play.

As in **Play mode**, you can edit the settings, use the metronome, and write a program.

 In this mode it is not possible to switch programs or to select bypass or mute.


Entering Individual mode


In Play mode press and hold the Bank switch for one second, and you will enter Individual mode. The name display will indicate “-INDIV-,” and the bank number display will indicate “=.”

When you enter **Individual mode**, the program LED's will indicate the on/off status of each effect block (synchronized with the effect block LED's).

DRIVE-AMP corresponds to program switch (LED) 1, **CABINET** to 2, **MODULATION** to 3, **AMBIENCE** to 4, and **PEDAL** to the expression pedal (pedal LED).

Each time you press a program switch, it will cycle on or off. For the pedal effect, pressing the expression pedal firmly will turn it on/off (the switch is located under the pedal). However for some pedal effects such as **SAMPLE & PLAY**, the expression pedal is used in a special way, and cannot be turned off once the pedal has been turned on.

 For some effects, it is not possible to simultaneously use the **MODULATION** and **PEDAL** effect blocks, or the **PEDAL** and **AMBIENCE** effect blocks. If you attempt to simultaneously turn on both of these effect blocks in such a combination, the effect block that was turned on first will automatically be turned off.



Exiting Individual mode

To return to **Play mode**, press either the bank switch or the EXIT switch.

Phrase Trainer mode

In this mode, you can record a phrase from an audio device (CD or MD) connected to the AUX IN jack, and play it back repeatedly as a loop. Then you can practice a phrase on your guitar while listening to the repeating phrase.

Since you can slow down the playback speed without affecting the pitch, this is a convenient way to learn or practice phrases from recordings that are difficult to play.

⚡ When you enter this mode, the **MODULATION**, **PEDAL**, and **AMBIENCE** effect blocks will automatically be turned off. (When you exit Phrase Trainer mode, the previous settings will be restored.)

1. Enter Phrase Trainer mode

From Play mode, simultaneously press and hold program switches 1 and 2 for one second. The MASTER/VALUE display will indicate the selected recording mode, and the Phrase Trainer icon will blink.

2. Select the recording mode

Use the MASTER/VALUE switches (▲, ▼) to select the recording mode. When the name display indicates "SHT," a maximum of 8 seconds can be recorded (high quality sound). When it indicates "LNG," a maximum of 16 seconds can be recorded (extended recording time). The phrase will be recorded and played back monaurally.

3. Begin recording

Start the audio device that is connected to the AX1000G, and press the bank switch (REC) at the point where you wish to begin recording. The name display will indicate "REC" and the number of seconds of recording.

⚡ Once you record a phrase, it is not possible to change the recording mode. If you wish to change the recording mode, you must return to Play mode, and once again enter Phrase Trainer mode.

4. Stop recording

At the point where you wish to stop recording, press program switch 2 (▶/||) or the bank switch (REC). Recording will end, and the name display will indicate "PLAY." The recorded phrase will automatically begin playing repeatedly as a loop. Recording will also end automatically if you continue recording for the maximum time length of the selected recording mode.

⚡ Depending on the volume of the connected audio device, the sound may be distorted. If this occurs, adjust the volume on the audio device.

⚡ The sound of your guitar will be muted during recording.

To re-do the recording

Press program switch 2 (▶/||) to stop playback. Then continue with step "3. Begin recording" and step "4. Stop recording."

To erase the recorded phrase

Press the EXIT button to delete the phrase. Alternatively, you can record a new phrase to overwrite the previously-recorded phrase.

5. Stop

When you press program switch 2 (▶/||), playback will stop. Press program switch 2 (▶/||) once again, and playback will resume from where you stopped.

- If program switch 1 (◀◀) is pressed while stopped, you will return to the beginning of the recorded phrase.
- By pressing the cursor switches, you can playback in reverse (◀) or forward (▶) as long as you hold down the switch.
- During recording or while stopped, the sound that is connected to the AUX input will be heard.
- When not recording, you can use the expression pedal to adjust the level of the effect sound.

6. Playback

During recording or while stopped, press program switch 2 (▶/||) to playback the recorded phrase as a repeating loop.

By pressing program switch 3 (SPEED) or the MASTER/VALUE switches (▲, ▼), you can slow down the playback speed without affecting the pitch.


- Each time you press program switch 3 (SPEED), the playback speed will cycle through settings of 100%, 75%, 50%, 25%, 100% ...
 - By pressing the MASTER/VALUE switches (▲, ▼), the speed can be adjusted in 5% steps; 100%, 95%, 90%, ... 25%.
- During playback, you can press cursor switch (▶) to playback at double speed as long as you continue pressing the switch.

If you press cursor switch (◀), the recording will play back in reverse as long as you continue pressing the switch.

If you press program switch 1 (◀◀), the recording will rewind as long as you continue pressing the switch.

7. Hold

By pressing program switch 4 (HOLD), you can hold the sound that was playing at the moment the switch was pressed. When you press the switch once again, hold will be defeated. By pressing a cursor switch while the sound is being held, you can playback backward (◀) or forward (▶) as long as you continue holding the switch. If you press program switch 1 (◀◀), you will go back one second, cancel Hold, and begin playback.



Rewind/Cue Change playback speed Start/stop recording

Exiting Phrase Trainer mode

To return to Play mode, you can either press program switches 1 and 2 simultaneously, or press the EXIT switch.


⚡ When you exit Phrase Trainer mode or turn off the power, the recorded phrase will be erased.

3. Editing

In Play mode and Individual mode, you can edit each effect, set noise reduction and program level, and modify the program name.

In Phrase Trainer mode, it is possible to edit the **DRIVE-AMP** and **CABINET** effect blocks, but it is not possible to perform editing operations that use the name display or MASTER/VALUE display, or the cursor switches or the MASTER/VALUE switches.

During editing, the edit icon in the display will blink.



Editing effects


Rotate the effect select knob of the effect block that you wish to edit, or press the corresponding effect block select switch. The effect block LED will begin blinking, indicating that it has been selected for editing.

Use the effect select knob, effect block select switch, and value knobs to edit the settings.

If you wish to save the edited effect, perform the "Program write" operation. If you fail to do this, the effect program will revert to its original settings when you turn off the power or select a different program.

As an example, we will explain how to edit the **TUBE OD (Tube Overdrive)** effect of the **DRIVE-AMP** block.

1. If the name display indicated "TUBE OD" when you pressed the effect block select switch, simply continue. If not, turn the **DRIVE-AMP** effect select knob to the **TUBE OD** position. If the effect select knob was already located at **TUBE OD**, first select a different effect model, and then turn the knob back to **TUBE OD**.
2. The effect block LED will begin blinking, indicating that it has been selected for editing. (The name display will indicate the model name as "TUBE OD.") If you selected a programmed effect, the **ORIG** icon will light.
3. The five value LEDs will light, and the corresponding value knobs will be assigned to **DRIVE**, **LEVEL**, **TREBLE**, **MIDDLE**, and **BASS** respectively, and will function as knobs that adjust the value of each parameter. (Refer to p.16, "Effect parameters.")
4. Rotate the knobs and the sound will change. The name display will indicate the name of the parameter assigned to that knob, and the MASTER/VALUE display will indicate the value. At this time, the **ORIG** icon will light when the position of the knob matches the original value — i.e., the value before you began editing.



Instead of the five value knobs, you can also use the cursor switches to select parameters, and use the MASTER/VALUE switches (▲, ▼) to adjust the value of the parameter currently shown in the name display.

If you do not wish to use the **DRIVE-AMP** effect block, press the **DRIVE-AMP** effect block select switch until the LED goes dark. The **DRIVE-AMP** effect block is now bypassed, and the name display will indicate "OFF."

For some effects, it is not possible to simultaneously use the **MODULATION** and **PEDAL** effect blocks, or the **PEDAL** and **AMBIENCE** effect blocks. If you attempt to turn on both effect blocks in such a combination, the block that had been turned on will automatically be turned off.

Quick Editing for the DRIVE-AMP effect block

In the default state of each mode, the **DRIVE-AMP** effect block parameters used by the selected program are assigned to the value knobs (except when the effect is off).


By rotating the respective value knobs, you will enter Edit mode (the effect block LED will blink); the name display will indicate the parameter name, the MASTER/VALUE display will show the value, and the sound will change.

If you wish to change an effect that is in use, use the effect select knobs to select the desired effect.

It is not possible to edit when other functions are assigned to the value knobs, when the **AX1000G** is bypassed, muted, or recording in Phrase Trainer mode.

Setting the noise reduction and program levels

1. If you are in Play mode, press the NR-LEVEL switch.
2. By rotating value knobs 1 or 2, or pressing the NR-LEVEL switch, you can access the screen displays for adjusting the noise reduction and setting the level for each program.
3. To adjust the amount of noise reduction, use value knob 1 (range OFF...10: shown in the MASTER/VALUE display).
4. To adjust the level of each program, use value knob 2 (range 0...10: shown in the MASTER/VALUE display).
5. When you finish making settings, press the EXIT switch to return to Play mode.




Instead of value knobs 1 and 2, you can also use the cursor switches to select a parameter and use the MASTER/VALUE switches (▲,▼) to adjust the value of the parameter.

- ⚠ It is not possible to turn noise reduction off.
- ⚠ Depending on the guitar that you use, raising the noise reduction setting too high may cause the sound to be cut off at low levels.
- ⚠ The volume of each program will change depending on the guitar that you use. Adjust the program level for your guitar.
- ⚠ If you wish to save the noise reduction and program level settings that you edited, you must perform the "Program write" operation. If you turn off the power or select a different program without writing the program, the program you modified will revert to its previous settings.

Modifying program names

Press the RENAME switch and specify the desired program name. Use the cursor switches (◀, ▶) to select the character that you wish to change (the character will blink). Then use value knob 5 (or the MASTER/VALUE switches) to select the desired character. The available characters are shown below.




- ⚠ If you wish to save the modified program name, you must perform the "Program write" operation. If you turn off the power or select a different program without writing the program, the program name you edited will revert to its previous setting.

Writing programs

Here's how to write an edited program.

1. Press the WRITE switch, and the name display will indicate "*WRITE*." The bank number display and the program LED will blink.
2. Use the MASTER/VALUE switches (or value knob 5 and the bank switch) to select the writing destination bank, and use the cursor switches (or the program switch) to select the writing destination program.
3. Press the WRITE switch once again, and the display will read "COMPLT" to indicate that the program has been written. You will then return to Play mode.

If you decide not to write, press the EXIT switch to cancel the Write operation.



- ⚠ If you write an edited program to a different program number, the program that was overwritten will be lost.
- ⚠ It is not possible to write to a preset program.

Troubleshooting

If you suspect a malfunction, please check the following points first. If this does not resolve the problem, contact a nearby dealer.

1. Power does not turn on

- Is the AC adapter plugged into an AC outlet? (☞p.6, 8)
- Is the included AC adapter connected? (☞p.6, 8)

2. No sound

- Are your guitar, amp, and headphones respectively connected to the correct jack? (☞p.6, 8)
- Is the power of your amp turned on, and is it set accordingly?
- Is one of your connection cables broken?
- Is the master level of the **AX1000G** set to “0” or to a low value? (☞p.8)
- Is the program level of the **AX1000G** set to “0” or to a low value? (☞p.13)
- Is the **LEVEL** of the **DRIVE-AMP** effect set to “0” or to a low value?
- Is the volume of your guitar turned down?
- Is the **AX1000G** muted?
- If **VOLUME** is selected for the **PEDAL** effect, has the pedal been returned to the full back position?

3. Effects are not applied

- Is the **AX1000G** bypassed? (☞p.9)
- Are the effects used by the program turned on? (☞p.4, 9)

4. Metronome does not function

- Are you in **Play mode** or in **Individual mode**?
The metronome will not function in **Phrase Trainer mode**.
- Is the metronome output level set to “0”? (☞p.9)


5. Pedal does not function

- Have you selected a program that uses an effect in the **PEDAL** effect block? (☞p.9)
- Is the pedal LED lit? (☞p.9)
- Try adjusting (calibrating) the expression pedal. (☞p.14)

6. Cannot write (the name display indicates “ERROR”)

- Reload the preset programs. (☞p.14)

Main specifications

- Number of effects: 56 types (maximum number of effects usable simultaneously: 8)
- Number of programs: 80 (40 preset, 40 user)
- Inputs: Guitar input (mono phone jack)
AUX IN (stereo mini jack)
- Outputs: Output x 2 (mono phone jack)
Headphones (stereo mini jack)
- Tuner section
Detection range: 27.5 Hz — 2,093 Hz (A0—C7)
Calibration: A=438—445 Hz
- Metronome section
Tempo: bpm= 40—208
- Power supply: DC9V (included AC adapter )
- Dimensions: 420 (W) x 187.7 (D) x 65.4 (H) mm
- Weight: 2.4kg
- Included items: Owner’s manual
AC adapter

* Specifications and appearance are subject to change with out notice for improvement.

CABINET effect block

The shape of the cabinet and the type and number of speakers are very important elements in determining the tonal character of a guitar amp.

The CABINET effect block provides models that faithfully simulate the cabinet and speaker characteristics of a variety of guitar amps, from vintage to modern.

Although these models are especially effective when you are plugged in to a mixer etc. via a direct line connection, they are also effective when you are using a guitar amp.

CABINET	Knob 1 AIR	Knob 2 LEVEL	Knob 3 PRESENCE	Knob 4	Knob 5
1x8 TWEED	AP, 0.3...9.7, Ln	1...10	0...10		
1x12 TWEED	AP, 0.3...9.7, Ln	1...10	0...10		
1x12 BLACK PANEL	AP, 0.3...9.7, Ln	1...10	0...10		
1x12 AC15	AP, 0.3...9.7, Ln	1...10	0...10		
2x12 BLACK PANEL	AP, 0.3...9.7, Ln	1...10	0...10		
2x12 AC30	AP, 0.3...9.7, Ln	1...10	0...10		
2x12 CLASS A	AP, 0.3...9.7, Ln	1...10	0...10		
4x10 TWEED	AP, 0.3...9.7, Ln	1...10	0...10		
4x12 CLASSIC	AP, 0.3...9.7, Ln	1...10	0...10		
4x12 VINTAGE	AP, 0.3...9.7, Ln	1...10	0...10		
4x12 MODERN	AP, 0.3...9.7, Ln	1...10	0...10		

1x8 TWEED "1-8 TWD"

This model simulates an open back cabinet with one 8-inch speaker.

1x12 TWEED "1-12 TWD"

This model simulates an open back cabinet with one 12-inch speaker typically used for blues.

1x12 BLACK PANEL "1-12 BLK"

This model simulates an American open back cabinet with one 12-inch speaker and a bright tonal character.

1x12 AC15 "1-12AC15"

This model simulates a Vox open back cabinet with one 12-inch "Blue" speaker.

2x12 BLACK PANEL "2-12 BLK"

This model simulates an American open back cabinet with two 12-inch speakers.

2x12 AC30 "2-12AC30"

This model simulates a Vox open back cabinet with two 12-inch "Blue" speakers.

2x12 CLASS A "2-12 CLA"

This model simulates a modern open back cabinet with two 12-inch speakers.

4x10 TWEED "4-10 TWD"

This simulates an open back cabinet with four 10-inch speakers.

4x12 CLASSIC "4-12 CLS"

This simulates a closed back cabinet with four 25W 12-inch speakers.

4x12 VINTAGE "4-12 VIN"

This simulates a closed back cabinet with four 30W 12-inch speakers.

4x12 MODERN "4-12 MDN"

This simulates a closed back cabinet with four 75W 12-inch speakers.

Knob 1 AIR

This simulates the resonance of the cabinet, and the comb filtering effect produced by interference between the speakers.

Decreasing this value will produce a sound that is more suitable for connection to a guitar amp. Increasing this value will produce a sound that is more suitable for direct-line connection.

Knob 2 LEVEL Adjusts output level.

Knob 3 PRESENCE Adjusts tone of the high-frequency range.



If the sound distorts, slightly lower the **LEVEL** and **PRESENCE**.

Pitch shifter

This effect modifies the pitch.

PITCH SHIFTER "PITCH"

This pitch shifter can be adjusted over a +/-2 octave range.

- Knob 1 **TIME** Adjusts delay time.
- Knob 2 **FEEDBACK** Adjusts amount of feedback (delay repeats).
- Knob 3 **PITCH** Adjusts amount of pitch change.
- Knob 4 **FINE** Fine adjustment for the amount of pitch change.
- Knob 5 **MIX** Adjusts mix amount of effect sound.

Auto wah

This is an auto-wah filter that automatically opens and closes according to the attack with which you play your guitar. The effect will vary depending on the guitars volume setting.

FILTRON "FILTRON"

This is a low-pass filter type auto-wah.

- Knob 1 **TIME** Adjust the speed at which the wah will rise in response to your picking.
- Knob 2 **FEEDBACK** Adjust the peak of the wah sound.
- Knob 3 _____
- Knob 4 **DEPTH** Adjust the sensitivity with which the wah will respond to your picking.
- Knob 5 **POLARITY** Specify the direction in which the wah will operate.

AUTO WAH "AUTOWAH"

This is a band-pass filter type auto-wah that is equivalent to a pedal wah. It is placed before the DRIVE-AMP effect block.

- Knob 1 **TIME** Adjust the speed at which the wah will rise in response to your picking.
- Knob 2 _____
- Knob 3 _____
- Knob 4 **DEPTH** Adjust the sensitivity with which the wah will respond to your picking.
- Knob 5 **POLARITY** Specify the direction in which the wah will operate.

Octave

This generates a pitch one octave lower than the original sound, and mixes it with the original sound to add a sense of depth and low end.




This effect may not operate correctly if two or more strings are played simultaneously, or when low-pitched strings are played.

OCTAVE "OCTAVE"

- Knob 4 **DEPTH** Adjust the amount of the ultra-low pitch (one octave below).
- Knob 5 **MIX** Adjust the amount of the original sound.

Pitch bend


This is a Pitch shifter that uses the pedal to control the pitch.

 If you use this effect in a program where the **MODULATION** effect block is on, the **MODULATION** effect block will automatically be turned off.

PITCH BEND	“P BEND”
Knob 1 TIME	Adjust the delay time.
Knob 2 FEEDBACK	Adjust the amount of feedback (delay repeats).
Knob 3 PITCH	Adjust the amount of pitch change.
Knob 4 FINE	Make fine adjustments to the amount of pitch change.
Knob 5 MIX	Adjust the mix amount of the effect. With a setting of 10, only the effect sound will be output.

Ring modulator


This effect multiplies the original sound with a sine wave to produce bell-like effects. The cleanest results will be produced if you use the neck pickup of your guitar, turn down the tone, and pluck the string near the twelfth fret.

 If you use this effect in a program where the **MODULATION** effect block is on, the **MODULATION** effect block will automatically be turned off.

RING MOD	“RINGMOD”
This is a ring modulator that lets you use the pedal to control the frequency.	
Knob 3 PITCH	Adjust the tone when the pedal is advanced.

Delay


These effects mix a time-delayed sound with the original sound to add depth and spaciousness to the sound.

 If you use this effect in a program where the **AMBIENCE** effect block is on, the **AMBIENCE** effect block will automatically be turned off.

HOLD DELAY “HOLDDLY”
This will normally function as a delay, but when the pedal is advanced all the way forward to press the switch, the pedal LED will light and the sound will be held (the delay sound will continue to be heard). Since you can use the pedal to control the input level to the delay, you can easily produce special effects such as sound-on-sound.




TAP DELAY	“TAP DLY”
This is a tap tempo delay that allows you to set the delay tempo by pressing the pedal switch twice. While the tempo is being specified, the pedal LED will light.	
Knob 1 TIME	Adjust the delay time.
Knob 2 FEEDBACK	Adjust the feedback amount (delay repeats).
Knob 3 TONE	Adjust the tone of the effect sound.
Knob 4 _____	_____
Knob 5 MIX	Adjust the mix amount of the effect sound.

Sample and play

 If you use this effect in a program where the **AMBIENCE** effect block is on, the **AMBIENCE** effect block will automatically be turned off.

SAMPLE&PLAY “S+PLAY”

This allows approximately 8 seconds of recording. By using the reverse setting, you can produce special “scratch” effects.

1. Press the expression pedal all the way to enter record-ready mode. The pedal LED will blink.
 2. Play a phrase etc. on your guitar. Recording will begin automatically, and the pedal LED will light.
 3. When the recording time specified by **TIME** has elapsed, recording will end and the pedal LED will not be lit. Alternatively, you can stop recording before the specified recording time has elapsed by pressing the pedal all the way (i.e., pressing the pedal switch). To re-do the recording, repeat the procedure from step 1.
-  During recording, you can also return the pedal and then press it again to stop recording and begin playback.
4. Operate the expression pedal. When you advance the pedal, the recorded phrase will playback. If you have set **REVERSE** to **x1—x8**, returning the pedal will cause the sound to playback in reverse at the specified speed. If you set **REVERSE** to **OFF**, the sound will only playback forward. With a setting of **LP1** or **LP2**, advancing the pedal will playback the sound as a repeating loop. When you return the pedal and then advance the pedal again, playback will begin from the beginning.
-  Recording will not begin unless you play your guitar louder than the threshold.
-  The recording sound will be erased when you enter Phrase Trainer mode or when you turn off the power.

Knob 1 TIME	Specify the sample time (recording time).
Knob 2 REVERSE	OFF : When you press the pedal, the sound will playback to the end and then stop. x1—x8 : Press the pedal to playback, and return the pedal to playback in reverse. LP1 : Press the pedal to playback as a loop, and return the pedal to stop. LP2 : Press the pedal to playback as a loop, and return the pedal to playback to the end and then stop.
Knob 3 _____	_____
Knob 4 _____	_____
Knob 5 MIX	Adjust the output level of the sampled sound.

Preset Program Parameter List

When an effect block that was off is turned on, the effect model printed in a slanted typeface will be selected.

A cabinet model appropriate for each program is selected in the CABINET effect block. If you will be using a direct output connection to a mixer etc., you should turn on the CABINET effect block.

BANK#	PROGRAM	DRIVE-AMP	CABINET	MODULATION	PEDAL	AMBIENCE	NR-PRG
0	1 60'S	BIG FUZZ Value— 7.3 5.3 5 7 4.7	<i>2x12 AC30</i> 2.3 8 4.3	<i>TEXTREM</i> — 8 6.7 —	VOLUME — — — 0	ECHO PLUS 112 3.3 4 — 3.3	4 10
	2 70'S	FAT DIST Value— 5.7 5.7 6.7 5.7 7.3	<i>4x10 TWEED</i> 2 8 4.3	<i>BLACK PHASER</i> — 1.3 0.14 —	VOLUME — — — 0	MULTI HEAD ECHO 356 3.7 4.7 3 3.7	3 10
	3 80'S	CLASSIC DIST Value— 9.3 6 3 5.7 7.3	<i>4x12 VINTAGE</i> 3 9 4.7	MOD DELAY 9.5 3.7 0.38 4.3 6.0	VOLUME — — — 0	ECHO HALL 101 4 7 4.3 1	4 10
	4 90'S	METAL DIST Value— 9 6.7 4 4 6.7	<i>4x12 MODERN</i> 1.7 8 6.3	<i>MOD DELAY</i> 625 0 0.32 4.3 6	VOLUME — — — 0	ECHO ROOM 61 0 5 6.3 4.7	4 10
1	1 TELBILY	TUBE OD Value— 3 10 2 2.7 1.7	<i>1x12 BLACK PANEL</i> 1.7 6 7	<i>TEXTREM</i> — 4 5.3 —	VOLUME — — — 0	ECHO ROOM 125 4.3 10 7.3 6.7	OFF 10
	2 TRIPPER	TOP BOOST Value— 2.7 9 6.7 4 7	<i>2x12 AC30</i> 2 8 4.3	<i>CLASSIC CHORUS</i> — 1 5 1	VOLUME — — — 0	ROOM 2.7 — 6.7 — 5	3 10
	3 VOODOO1	BIG FUZZ Value— 5.7 6.7 5.7 3 4.3	<i>4x12 CLASSIC</i> 0.7 7 4.7	<i>AUTO WAH</i> 4 — — 5.3 UP	VOX WAH — — — —	HALL 5.3 — 1.7 — 3.3	6 10
	4 VOODOO2	BIG FUZZ Value— 7 6 4.3 6 4.3	<i>4x12 CLASSIC</i> 1 9 3.7	<i>BLACK PHASER</i> — 0 8.0 —	U-VIBE — — — 5.7 1	PLATE 3.3 — 10 — 2.7	6 10
2	1 SUGAR	TUBE OD Value— 6.7 7 4.7 3 8	<i>1x12 AC15</i> 2 10 0.7	<i>CLASSIC CHORUS</i> — 2 4.7 1	CHORUS/FLANGER 5.7 0 0.2 5.3 —	HALL 7.7 — 5.3 — 3	3 10
	2 Z*P*L*N	FAT DIST Value— 4.3 7.3 2.3 3.7 8.7	<i>4x12 VINTAGE</i> 1 8 6	<i>ORANGE PHASER</i> — 7.3 0.18 —	VOLUME — — — 0	ECHO HALL 80 4.3 5.3 5.3 1.7	4 10
	3 LIZZY	BRIT STACK Value— 6.7 5.7 6.7 5.7 6.3	<i>4x12 VINTAGE</i> 2.3 7 5.7	<i>PITCH SHIFTER</i> 0 0 —12 0 10	PITCH BEND 0 0 —12 0 5	PLATE 3.3 — 9 — 3.7	6 10
	4 WARPIGS	BIG FUZZ Value— 8 7 6.3 0 4.3	<i>4x12 VINTAGE</i> 2.3 8 5.7	<i>MOD DELAY</i> 529 4 0.5 6.3 5.3	VOLUME — — — 0	PLATE 3.3 — 9 — 3.3	6 10
3	1 SUMMER	CLASSIC COMP Value— 1 8.3 4.3 3 8	<i>2x12 BLACK PANEL</i> 1 8 5.3	MOD DELAY 494 0 0.1 6 6.3	VOLUME — — — 0	STEREO DELAY 188 4.7 3 — 4	OFF 10
	2 SCREAM	TUBE OD Value— 7.3 7.3 2.3 5 7	<i>4x12 VINTAGE</i> AP 8 0	<i>ORANGE PHASER</i> — 3.7 8 —	VOLUME — — — 0	ROOM 6 — 2.3 — 2.7	2.3 10
	3 MR-FV	FAT DIST Value— 9.7 7 4 3 5	<i>4x12 MODERN</i> LN 9 4.3	<i>AUTO WAH</i> 8.3 — — 4.7 UP	VOX WAH — — — —	ECHO PLUS 420 4.7 4.7 — 4	6 10
	4 AIN'T	CLASSIC DIST Value— 10 7 2.3 4.7 9	<i>4x12 CLASSIC</i> 0.7 8 7.3	<i>CLASSIC FLANGER</i> 1.3 4 0.26 3.3 —	CHORUS/FLANGER 1 4 0.26 3 —	MULTI HEAD ECHO 230 0 1.7 1 3.7	4 10
4	1 TALLICA	ACOUSTIC Value— 7.3 6.7 9.7 3 8	<i>1x12 TWEED</i> 1 7 10	STEREO CHORUS 3.3 — 0.38 5.7 —	VOLUME — — — 0	HALL 7.7 — 5.3 — 2.3	2.3 10
	2 90'SVOX	TOP BOOST Value— 4 8 3.3 5 8	<i>2x12 AC30</i> AP 9 0.3	<i>TEXTREM</i> — 8 6.7 —	VOLUME — — — 0	SPRING 4.3 — 5.3 — 2.3	OFF 10
	3 CORN	METAL DIST Value— 9 6 8.3 2 8	<i>4x12 CLASSIC</i> 1.7 8 5.7	<i>MOD DELAY</i> 324 0 0.6 5.7 6.3	VOLUME — — — 0	ROOM 2.7 — 6.7 — 2.3	6.3 10
	4 DYME	METAL DST Value— 10 6.3 8.7 1 6	<i>4x12 MODERN</i> 1.3 8 6	<i>BLACK PHASER</i> — 2.3 0.1 —	VOLUME — — — 0	ROOM 2.7 — 6.7 — 3.3	7 10
5	1 3-HEAD-	TOP BOOST Value— 8.3 6.3 3 7 2.3	<i>2x12 AC30</i> 2.7 7 4.3	STEREO CHORUS 1.3 — 0.14 3 —	VOLUME — — — 0	MULTI HEAD ECHO 463 3.7 5.7 3 3.7	3 10
	2 TAP DLY	TUBE OD Value— 7 7.7 0.7 4.3 6.3	<i>1x12 BLACK PANEL</i> 1.3 7 0.3	<i>MOD DELAY</i> 729 3.7 0.26 4.7 5.7	TAP DELAY 750 3.7 4 — 7.7	HALL 6.7 — 3.3 — 4.7	3 10
	3 TOWER	SEATTLE Value— 2 6.3 6 4.7 6.3	<i>4x12 VINTAGE</i> 0.7 8 5.7	<i>OCTAVE</i> — — — 3.3 10	VOLUME — — — 0	MULTI HEAD ECHO 180 4.3 6 1 5	3 10
	4 MONSTER	METAL DIST Value— 10 7.7 2.3 2.7 6.3	<i>1x12 TWEED</i> 1 7 8.3	<i>PITCH SHIFTER</i> 0 0 7 0 10	VOLUME — — — 0	ECHO PLUS 655 5.7 5.3 — 5.3	6 10
6	1 HOLD	CLASSIC COMP Value— 5.7 8 1.3 4.7 8.3	<i>1x12 AC15</i> 1 7 4	STEREO CHORUS 1.7 — 1 5 —	HOLD DELAY 3.0 0 5.3 — 8.7	STEREO DELAY 750 5 5.3 — 5	OFF 10
	2 S+P SLW	TOP BOOST Value— 8.3 6 4.3 5.7 7	<i>2x12 CLASS A</i> 1 8 5	<i>MOD DELAY</i> 841 4 0.6 6.3 3.7	SAMPLE&PLAY 8 1 — — 8.7	PLATE 2 — 5 — 6.3	3 10
	3 S+P FST	US HI-GAIN Value— 10 7 3.7 2.7 6.3	<i>4x10 TWEED</i> 0.7 6 7.3	STEREO CHORUS 3.3 — — 0.38 5.7	SAMPLE&PLAY 8 3 — — 8.7	PING PONG DELAY 2 4 6.3 — 5	5 10
	4 S/LOOP	BRIT STACK Value— 8.7 7 2.7 2.7 7	<i>4x12 MODERN</i> 2.7 9 5	STEREO CHORUS 3.3 — 0.38 5.7	SAMPLE&PLAY 8 LP2 — — 8.7	SPRING 3.3 — 8 — 5.3	6 10
7	1 AC/CHOR	ACOUSTIC Value— 5 9.3 6.7 6.3 6.3	<i>1x8 TWEED</i> 1 8 9.7	STEREO CHORUS 3.3 — 0.44 5.7 —	VOLUME — — — 0	PLATE 3.3 — 9 — 5	3 10
	2 CHORUS	CLASSIC COMP Value— 2.7 7 8.3 5.7 6	<i>2x12 AC30</i> 7.7 8 1.3	STEREO CHORUS 3.3 — 0.8 4 —	VOLUME — — — 0	SPRING 3.3 — 8 — 6	OFF 10
	3 PHASCLN	CLASSIC COMP Value— 2 9.3 5.3 1 7.3	<i>1x12 BLACK PANEL</i> 1 7 8	<i>BLACK PHASER</i> — 1 0.14 —	VOLUME — — — 0	ECHO+ROOM 45 0 5.3 3.3 4	2 10
	4 FLANGE	FAT DIST Value— 9.3 7.7 0.7 2.3 4.3	<i>1x12 BLACK PANEL</i> 1 8 7.7	<i>CLASSIC FLANGER</i> 1.7 3.3 0.16 8.3 —	VOLUME — — — 0	HALL 10 — 1.7 — 2.7	6 10
8	1 FILTRON	CLASSIC COMP Value— 2 9 4 2 8.3	<i>2x12 AC30</i> 3.3 8 2.7	FILTRON 7 6 — 3.3 UP	VOLUME — — — 0	SPRING 7.3 — 5 — 5	3 10
	2 TRAVEL	TOP BOOST Value— 4 6.7 3 7 7.3	<i>2x12 AC30</i> 8.7 8 3.3	<i>BLACK PHASER</i> — 3.3 0.6 —	TRAVELER — 6.7 — 7	ROOM 4 — 1.7 — 3	3 10
	3 FZ WAH	BIG FUZZ Value— 5.7 6.3 4.7 4 7	<i>4x12 MODERN</i> 1.7 9 5	<i>AUTOWAH</i> 2.3 — — 6.3 DN	VOLUME — — — 0	HALL 4.7 — 6.7 — 4	6 10
	4 G + R	FAT DIST Value— 10 6.3 3.7 4 6.7	<i>4x12 VINTAGE</i> 1 7 5	<i>ORANGE PHASER</i> — 5 9 —	VOX WAH — — — —	ECHO+PLATE 1.2 4 7.3 5.7 2	6 10
9	1 SPACE	CLASSIC COMP Value— 7.3 8.7 1 4 2.7	<i>1x12 BLACK PANEL</i> 1 9 6.7	<i>PITCH SHIFTER</i> 441 4.3 —5 0 10	PITCH BEND 441 4.3 12 0 5	HALL 3.3 — 5.3 — 5.3	3 10
	2 SUBHARM	SEATTLE Value— 7 6.7 2.3 4 5	<i>2x12 CLASS A</i> 1 6 6	<i>OCTAVE</i> — — — 6 10	VOLUME — — — 0	ECHO+PLATE 320 3 4.3 5.3 4	4 10
	3 RINGMAN	CLASSIC DIST Value— 7.3 7 1 4 8.7	<i>4x12 VIN</i> 1 6 8.3	<i>CLASSIC CHORUS</i> — 0.2 3.3 2 —	RING MOD — 7 — —	MULTI HEAD ECHO 1.37 2 8.3 3 3.7	7 10
	4 BIZKIT	BIG FUZZ Value— 10 4.7 8.3 6.3 5.3	<i>4x12 CLASSIC</i> 1 9 0.3	<i>MOD DELAY</i> 625 4 0.18 7.7 4	TALK 'A' 'E' 'I' — —	ROOM 3.3 — 9.3 — 6	7.3 10