

prologue System Firmware Update

Update Procedures


- ⚠ This updater is compatible with Windows 7 SP1 or later. Do not try to run it with Windows 98/Me/2000/XP/Vista.
- ⚠ The latest "KORG USB-MIDI Driver" needs to be installed before the update.
If the driver installed on your computer is older than the latest version, install the latest version of the driver before starting the update. (<http://www.korg.com>)
- ⚠ Do not operate the prologue or the computer during the update process.
- ⚠ Close all other applications before running the updater.
- ⚠ After updating, do not downgrade to a previous system version. The operation of a downgraded unit will not be guaranteed.

1. Unzip the "prologue_Updater_???_win.zip". (??? is version number)


- ⚠ Extract all the files in the zip file before proceeding to step 3. The updater may not be able to find necessary files if they were not unzipped.

Update System Firmware

2. Turn on the prologue while holding the [6] and [8] buttons. This will enter the version upgrade mode.




3. Execute the "kmupdate.exe". The following window will appear.




4. Push the Update button in the window to start the process.

▲ If the following message is shown, the system firmware is already up to date, and no change is needed. In this case simply quit the KORG System Updater.




▲ If an "Error message" is shown, confirm that the "prologue" is connected to the computer properly, or that the "KORG USB-MIDI Driver 1.2.3 r14 or later" has already been installed.

5. During the updating process, the following window will appear. The whole process might take several minutes to complete.




 **Do not turn off the prologue during the update process.**

6. The following message will be shown when the update has successfully completed. This will conclude the entire update procedure.



7. Quit the KORGE System Updater.
8. Turn on the prologue while holding button [8]. The current system, panel and voice versions will be shown on the OLED display.
9. If a "-" appears next to the panel or voice version number, additional updates are required.

- 10.** When a panel update is required, turn on the prologue while holding the [6], [EXIT] and [SHIFT] buttons. This will enter the panel version upgrade mode.




⚠ During a panel version upgrade nothing will be displayed. Once the upgrade is complete "Update complete" will be displayed.

⚠ Do not turn off the prologue during the update process.

In this case please wait until it completes and "Update complete" is shown on the OLED display, then turn the power off, and on again.

- 11.** When a voice update is required, turn on the prologue while holding the [5], [EXIT] and [SHIFT] buttons. This will enter the voice version upgrade mode.



⚠ Do not turn off the prologue during the update process.

In this case please wait until it completes and "Update complete" is shown on the OLED display, then turn the power off, and on again.