


KAOSS DJ System Firmware Update


Update Procedures for Windows users

- 🔧 This updater is compatible with Windows 7 SP1 or later.
 - 🔧 When USB-MIDI device is connected to your PC, updater may not start process.
Please remove other USB-MIDI devices from your PC.
 - 🔧 Do not operate the KAOSS DJ or the computer during the update process.
1. Unzip the "KaossDJ_Updater_V###_win.zip". (### is version number)
 - 🔧 Extract all the files in the zip file before proceeding to step 3.
The updater may not be able to find necessary files if they were not unzipped.
 2. Turn on the power of the KAOSS DJ while holding the [A], [B] and [Touch Pad Mode] buttons. This will put it in "Update Mode".




- 🔧 Please confirm that it is displayed with "IPL" by LED.

3. Execute the "kmupdate.exe". The following window will appear.
(This is the image of the updater window when the KAOSS DJ version is 1.04)




4. Push the [Update] button in the window to start the process.

- ⚠ If "Already the latest system" message is shown, the system firmware is already up to date.
In this case simply quit the KORG System Updater.




- ⚠ The updater cannot recognize the KAOSS DJ if step 2 and step 3 are not done in the right order.

5. During the updating process, the following window will appear. The whole process might take several minutes to complete.



⚠ Do not disconnect the KAOSS DJ from the computer or turn off the power to the KAOSS DJ during the update process.

6. The following message will be shown when the update has successfully completed. This will conclude the entire update procedure.



7. Quite the KORG System Updater, and reboot the KAOSS DJ.
8. Turn on the power of the KAOSS DJ while holding the [B],[TAP],[Touch Pad Mode] buttons. You can confirm the current system version.