

EK-50 Ver 1.4 Release Information


Changes in Ver 1.4 from Ver 1.3

Bug fix

- A few low-level software bugs have been fixed.


What you will need

- USB Memory stick supported by EK-50
- Computer with USB port
- AC adapter KA390 or eight AA batteries

 **Make sure the batteries are brand new if using alkaline or fully charged if using NiMH batteries.**

Updating the software

- Prepare a memory stick that has been formatted by EK-50.
- Insert the memory stick into your computer.
- Extract EK-50_xxxx.zip.
- Copy "SYSTEM.BIN" on the root of the memory stick.
- Insert the memory stick containing the new system file into your EK-50, and turn on the power.
- Select "[SystemUpdate]" from the Media menu.



- Press Media button. Select "Yes [MEDIA]" by encoder and press Media button again. New version will appear. Press Media button.



- A confirmation message will appear. Select “Yes [MEDIA]” by encoder. Press Media button to begin the update operation.



 Do not turn off EK-50 while update is in progress.

- EK-50 will display the following screen when update is complete.



- Long push the power button. EK-50 will now turn off. The system has been updated.