

How to Install Accordion Type and Scene Data

1. Copy the following files to the **root directory** of your USB memory.
 - .dxs: Library file
 - .xml: Accordion file
 - .sca: Scene file
2. Power on the instrument.
3. Insert the USB memory into the USB port.
4. On the instrument, go to:
MENU → ACCORDION → REED SOUND LIBRARY → ADD LIBRARY
Select the Library (**Xs** icon displayed) to save. For details, refer to the instruction manual p.86.
5. Then go to:
MENU → ACCORDION → TYPE → IMPORT
Select the Accordion Type (**At** icon displayed) and save to the internal memory. Refer to Owner's Manual on page 39.
6. Next, go to:
MENU → SCENE → USB RECALL
Choose the Scene (**S** icon displayed) you want to import.
After recalling the Scene, press the [MENU/EXIT] button three times to return to the Home Screen. Then press and hold (for 2 seconds) one of the Scene buttons [A]–[F] on the panel to save the recalled Scene to the internal memory. Refer to Owner's Manual on page 65.
Tip: For content that uses multiple scenes in sequence, please select the slot to save first according to the instructions provided for the content. If there are no specific instructions, you may freely choose any save destination.
Repeat this process if you want to import multiple Scenes.
7. Remove the USB memory.
8. Select your newly imported Scene, or use your existing Scenes and simply change the Accordion Type using the dedicated panel button. Enjoy!

追加サウンドのインストール方法

1. USBメモリーのルート・ディレクトリに、以下のファイルをコピーします。
 - .dxs: ライブラリー・ファイル
 - .xml: アコーディオン・ファイル
 - .sca: シーン・ファイル
2. 本機の電源をオンにします。
3. USBメモリーを本機のUSBポートに装着します。
4. 本機のページを以下の順に選びます。
MENU → ACCORDION → REED SOUND LIBRARY → ADD LIBRARY
ライブラリー (**Xs** アイコンが表示) を保存します。詳しくは取扱説明書p.86を参照してください。
5. ページを以下の順に選びます。
MENU → ACCORDION → TYPE → IMPORT
アコーディオン・タイプ (**At** アイコンが表示) を内部メモリーに保存します。詳しくは取扱説明書p.39を参照してください。
6. ページを以下の順に選びます。
MENU → SCENE → USB RECALL
保存するシーン (**S** アイコンが表示) を選びます。
[MENU/EXIT]ボタンを3回押してメイン・ページに戻ります。
次に、パネル上の[A]–[F]ボタンのいずれかを2秒程度長押しし、選んだシーンを内部メモリーに保存します。詳しくは取扱説明書p.65を参照してください。
Tip: 複数のシーンを連続的に使用するコンテンツの場合、最初に保存するスロットをコンテンツの指示に従って選択してください。特に指示がないときは保存先を自由に選択してください。
複数のシーンを追加するときは、この手順を繰り返してください。
7. USBメモリーを取り外します。
8. 追加したシーンを選んだり、既存のシーンでアコーディオン・タイプを変更したりして、新しいサウンドを楽しんでください。

KORG INC.

4015-2 Yanokuchi, Inagi-City, Tokyo 206-0812 JAPAN
© 2025 KORG INC. www.korg.com Published 12/2025