

i2/i3

Interactive Music Workstation

Performance Notes

KORG

ⓐ ⓑ ⓓ

Disk File Management

Because the *i2/i3* uses the MS-DOS* disk format, there are no restrictions on how to organize your disk files. If you find that you use arrangements most often, you can prepare a disk that contains only arrangement files. You can fit many of them on one disk, as they take up a relatively small amount of disk space (about 9 kilobytes).

If you create your own styles, you may want to create a "master" arrangement file which you can use with all of your style files. (Remember, there are 64 arrangements in each arrangement file, but only four styles in each style file.)

As you use the *i2/i3* more and more, you will find a strategy that works best for you.

Compatibility With X3 Data

The Korg X3 Music Workstation features the same program and song structure as the *i2/i3*. Because their disk formats are the same, you can load programs and songs directly from an X3 disk into the *i2/i3*. Likewise, you can load programs and songs directly from an *i2/i3* disk into the X3.

The programs will be loaded into the program locations as shown below:

X3 Programs		<i>i2/i3</i> Programs
A00-A63	↔	D11-D88
A64-A65	↔	Dr7-Dr8

Program Change events in the song tracks will be converted as follows:

X3		<i>i2/i3</i>
GM1-GM64	↔	A11-A88
GM65-GM128	↔	B11-B88
B00-B63	↔	C11-C88
A00-A63	↔	D11-D88
A64-A65	↔	Dr7-Dr8

A note to *i2* users:

The *i2* has an additional piano multisound (340:A.Piano 3) which is used in programs **A11 Piano** and **D11 i2 Piano**. Because program D11 resides in RAM, it can be accidentally erased or replaced. As a matter of fact, if you loaded the "AMERICA" files to listen to the demo backing sequences, you have already replaced the *i2 Piano* program with the *8' Piano* program from the "AMERICA.PCG" file. (Program A11 and multisound 340 both reside in ROM, and as such cannot be erased.)

We have provided the file "_I2DBANK.PCG" on the IFD-00P factory disk for the purpose of restoring the *i2 Piano* program. With the exception of program **D11 i2 Piano**, this file contains the same programs as the "AMERICA.PCG" file. Use either the Load All Program function or the Load One Program function to restore this program.

* MS-DOS is a registered trademark of Microsoft Corporation.

All trademarks or registered trademarks are the property of their respective holders.

Style List

(length in measures)

Style	Intro 1	Ending 1	Intro 2	Ending 2	Fill 1	Fill 2
11 Open Rock	8	[†] 5	8	[†] 11	1	1

Style	Intro 1	Ending 1	Intro 2	Ending 2	Fill 1	Fill 2
12 Pop Rock	8	[†] 7	8	3	1	1

Style	Intro 1	Ending 1	Intro 2	Ending 2	Fill 1	Fill 2
13 Hard Rock	9	[†] 11	8	[†] 4	1	1

Style	Intro 1	Ending 1	Intro 2	Ending 2	Fill 1	Fill 2
14 RockShuffl	8	[†] 6	4	3	1	1

Style	Intro 1	Ending 1	Intro 2	Ending 2	Fill 1	Fill 2
15 Half Time	8	[†] 7	8	3	1	1

Style	Intro 1	Ending 1	Intro 2	Ending 2	Fill 1	Fill 2
16 Lite Rock	8	8	9	8	1	1

Style	Intro 1	Ending 1	Intro 2	Ending 2	Fill 1	Fill 2
17 60's Dance	9	[†] 8	2	[†] 8	1	1

Style	Intro 1	Ending 1	Intro 2	Ending 2	Fill 1	Fill 2
18 60's Rock	5	5	4	[†] 6	1	1

Style	Intro 1	Ending 1	Intro 2	Ending 2	Fill 1	Fill 2
21 New Jack	4	[†] 4	4	4	1	1

Style	Intro 1	Ending 1	Intro 2	Ending 2	Fill 1	Fill 2
22 Dance Pop	1	[†] 5	4	[†] 4	1	1

Style	Intro 1	Ending 1	Intro 2	Ending 2	Fill 1	Fill 2
23 House	8	[†] 9	8	[†] 5	1	1

Style	Intro 1	Ending 1	Intro 2	Ending 2	Fill 1	Fill 2
24 Rap	6	[†] 9	4	5	1	1

Style	Intro 1	Ending 1	Intro 2	Ending 2	Fill 1	Fill 2
25 70's Disco	8	[†] 8	5	[†] 9	1	2

Style	Intro 1	Ending 1	Intro 2	Ending 2	Fill 1	Fill 2
26 R&B Shuffl	4	[†] 5	4	[†] 9	1	1

Style	Intro 1	Ending 1	Intro 2	Ending 2	Fill 1	Fill 2
27 R & B	4	[†] 10	5	6	1	1

Style	Intro 1	Ending 1	Intro 2	Ending 2	Fill 1	Fill 2
28 Reggae	3	[†] 3	2	[†] 5	1	1

KORG i2/i3 Performance Notes

Style	Intro 1	Ending 1	Intro 2	Ending 2	Fill 1	Fill 2
31 Big Band	12	†3	2	†5	1	1

Style	*Intro 1 Major/Minor		*Ending 1		Intro 2	Ending 2	Fill 1	Fill 2
32 Slow Swing	10	4	6	7	4	†8	1	1

Style	Intro 1	Ending 1	Intro 2	Ending 2	Fill 1	Fill 2
33 Blues	4	†6	4	†6	†4	†4

Style	Intro 1	Ending 1	Intro 2	Ending 2	Fill 1	Fill 2
34 Mid Shuffle	8	†5	2	†7	1	2

Style	Intro 1	Ending 1	Intro 2	Ending 2	Fill 1	Fill 2
35 Pop Shuffle	4	†8	8	10	2	2

Style	Intro 1	Ending 1	Intro 2	Ending 2	Fill 1	Fill 2
36 Motown	4	†4	5	4	1	1

Style	Intro 1	*Ending 1 Major/Minor		Intro 2	Ending 2	Fill 1	Fill 2
37 6/8 Oldies	2	3	2	9	†5	1	1

Style	Intro 1	Ending 1	Intro 2	Ending 2	Fill 1	Fill 2
38 Country	2	†6	4	5	1	1

Style	Intro 1	Ending 1	Intro 2	Ending 2	Fill 1	Fill 2
41 4/4 Ballad	5	6	6	†7	1	1

Style	Intro 1	Ending 1	Intro 2	Ending 2	Fill 1	Fill 2
42 Pop Ballad	6	†6	8	†7	1	1

Style	Intro 1	Ending 1	Intro 2	Ending 2	Fill 1	Fill 2
43 SlowShuffl	5	†8	4	†5	1	1

Style	Intro 1	Ending 1	Intro 2	Ending 2	Fill 1	Fill 2
44 RockBallad	4	†6	4	†7	1	1

Style	Intro 1	Ending 1	Intro 2	Ending 2	Fill 1	Fill 2
45 8 Beat 1	4	†6	4	†4	1	1

Style	Intro 1	Ending 1	Intro 2	Ending 2	Fill 1	Fill 2
46 8 Beat 2	5	†6	4	†6	1	1

Style	Intro 1	Ending 1	Intro 2	Ending 2	Fill 1	Fill 2
47 16 Beat 1	4	†6	4	6	1	1

Style	*Intro 1 Major/Minor		*Ending 1 Major/Minor		Intro 2	Ending 2	Fill 1	Fill 2
48 16 Beat 2	3	4	†5	†6	4	†6	1	1

KORG i2/i3 Performance Notes

Style	Intro 1	Ending 1	Intro 2	Ending 2	Fill 1	Fill 2
51 Bossa Nova	10	†11	8	†8	2	2

Style	*Intro 1 Major/Minor		Ending 1	Intro 2	Ending 2	Fill 1	Fill 2
52 Samba	5	4	†4	4	†4	1	2

Style	*Intro 1 Major/Minor		*Ending 1 Major/Minor		Intro 2	Ending 2	Fill 1	Fill 2
53 Salsa	8	4	†6	†5	4	6	1	1

Style	*Intro 1 Major/Minor		Ending 1	Intro 2	Ending 2	Fill 1	Fill 2
54 Mambo	4	6	†4	4	†4	1	1

Style	Intro 1	Ending 1	Intro 2	Ending 2	Fill 1	Fill 2
55 Fusion	9	4	12	4	1	1

Style	Intro 1	Ending 1	Intro 2	Ending 2	Fill 1	Fill 2
56 Latin	8	9	4	†4	1	1

Style	Intro 1	*Ending 1 Major/Minor		Intro 2	Ending 2	Fill 1	Fill 2
57 Pop Samba	8	10	11	4	†4	1	1

Style	Intro 1	*Ending 1 Major/Minor		Intro 2	Ending 2	Fill 1	Fill 2
58 Beguine	8	†6	†7	4	5	1	1

Style	Intro 1	Ending 1	Intro 2	Ending 2	Fill 1	Fill 2
61 Waltz	4	[†] 4	8	8	2	2

Style	Intro 1	Ending 1	Intro 2	Ending 2	Fill 1	Fill 2
62 Slow Waltz	4	[†] 7	9	[†] 9	2	2

Style	Intro 1	Ending 1	Intro 2	Ending 2	Fill 1	Fill 2
63 2/4 March	2	3	5	[†] 5	1	1

Style	Intro 1	Ending 1	Intro 2	Ending 2	Fill 1	Fill 2
64 Polka	4	[†] 2	5	4	2	2

Style	Intro 1	Ending 1	Intro 2	Ending 2	Fill 1	Fill 2
65 Cha Cha	8	9	4	4	1	2

Style	Intro 1	*Ending 1 Major/Minor		Intro 2	Ending 2	Fill 1	Fill 2
66 Tango	8	[†] 9	[†] 8	3	[†] 6	1	1

Style	Intro 1	Ending 1	Intro 2	Ending 2	Fill 1	Fill 2
67 Broadway	4	[†] 8	4	[†] 4	1	1

Style	*Intro 1 Major/Minor		*Ending 1 Major/Minor		Intro 2	Ending 2	Fill 1	Fill 2
68 Dixieland	3	4	4	2	2	[†] 2	1	2

[†]Ending can be used as fill

[‡]Fill can be used as intro

*Chord variations have different lengths

Arrangement List

Arrangement Name	Style Name	Program	Arrangement Name	Style Name	Program
11 Mick&Keith	11 Open Rock	A47 DistGuitar	51 Boston Boy	21 New Jack	D58 PowerSynth
12 Prog. Rock	13 Hard Rock	L C87 Lead Stab D58 PowerSynth	52 Night Jams	21 New Jack	S C11 MIDI Piano C81 Euro Bass
13 Shufflin'	14 RockShuffl	C24 Perc&Rotor	53 DanceGirls	22 Dance Pop	L D78 Mono Lead D76 Leeeed
14 Top40 Rock	12 Pop Rock	D11 Piano 8'	54 VogueHouse	23 House	L C62 Analog Pad D31 Vibra Bell
15 Rlflin'	11 Open Rock	A32 Perc Organ	55 Yoll' Rap	24 Rap	L B13 Tenor Sax C76 Trumpets!
16 Rock On!	13 Hard Rock	A47 DistGuitar	56 Groovin'	26 R&B Shuffl	C11 MIDI Piano
17 Don't Stop	14 RockShuffl	C11 MIDI Piano	57 RaveltUp	U1 Rave	L B37 Rezzo 4ths D77 Busy Boy
18 AOR Rock	12 Pop Rock	D11 Piano 8'	58 MirrorBall	25 70's Disco	C78 Brass Band
21 SouthernRk	15 Half Time	A33 BX-3 Organ	61 1,000 Hits	41 4/4 Ballad	C11 MIDI Piano
22 EasyRockin	16 Lite Rock	D11 Piano 8'	62 2,000 More	46 8 Beat 2	C15 Hard Tines
23 Love Songs	44 RockBallad	C11 MIDI Piano	63 Phil'sSong	42 Pop Ballad	C11 MIDI Piano
24 OldTimeR&R	18 60's Rock	D11 Piano 8'	64 The 1950's	37 6/8 Oldies	D11 Piano 8'
25 HalfTime	15 Half Time	A47 DistGuitar	65 Sad Songs	47 16 Beat 1	C11 MIDI Piano
26 Laid Back	16 Lite Rock	D11 Piano 8'	66 Dinkerhump	43 SlowShuffl	C11 MIDI Piano
27 Unplugged	44 RockBallad	B11 SopranoSax	67 When A Man	37 6/8 Oldies	B13 Tenor Sax
28 Beethoven	18 60's Rock	D11 Piano 8'	68 Baby, Baby	43 SlowShuffl	D52 TheStrings
31 Doctor	34 Mid Shuffle	D11 Piano 8'	71 AfterHours	32 Slow Swing	D42 FlugelHorn
32 The King	34 Mid Shuffle	B13 Tenor Sax	72 The Duke	31 Big Band	L C78 Brass Band C76 Trumpets!
33 TheFabFour	34 Mid Shuffle	C43 L&R E.Gtrs	73 The Avalon	67 Broadway	D11 Piano 8'
34 Surf City!	17 60's Dance	C21 60's Organ	74 Cookin'	31 Big Band	B12 Alto Sax
35 The Twist	17 60's Dance	B13 Tenor Sax	75 OlBlueEyes	31 Big Band	D11 Piano 8'
36 Pickin'!	38 Country	C41 Strummers	76 Moon Music	34 Mid Shuffle	S D44 Air Flute D11 Piano 8'
37 Nashville!	38 Country	C33 PedalSteel	77 SoulfulSax	48 16 Beat 2	B12 Alto Sax
38 Long Train	45 8 Beat 1	C11 MIDI Piano	78 Jammin'Sax	26 R&B Shuffl	B13 Tenor Sax
41 90's Funk	U3 Funky Jams	C78 Brass Band	81 Ipanema	51 Bossa Nova	D44 Air Flute
42 SongWriter	45 8 Beat 1	D11 Piano 8'	82 SambaDeSol	52 Samba	A24 Vibes
43 Solid Gold	35 Pop Shuffle	C78 Brass Band	83 Hot Salsa	53 Salsa	B22 Flute
44 Supremely	35 Pop Shuffle	D11 Piano 8'	84 Mambo Mama	54 Mambo	C73 PerkySaxes
45 Motown1968	36 Motown	L C42 E.Guitars C41 Strummers	85 Latin Pop	U2 Latin Pop	B22 Flute
46 Soul Bros.	27 R & B	C22 Gospel Org	86 Carnivale	57 Pop Samba	C11 MIDI Piano
47 Da Blues	33 Blues	A33 BX-3 Organ	87 StretchOut	55 Fusion	C47 StereoDist
48 Rasta Man	28 Reggae	C22 Gospel Org	88 Bourbon St	68 Dixieland	A82 Trombone

L:layer S:split

Program List

Bank A (General MIDI)

11	Piano	21	Celesta	31	Full Organ	41	ClassicGtr
12	BritePiano	22	Glocken	32	Perc Organ	42	A.Guitar
13	HammerPno	23	Music Box	33	BX-3 Organ	43	JazzGuitar
14	HonkeyTonk	24	Vibes	34	ChurchPipe	44	Clean Gtr
15	New Tines	25	Marimba	35	Positive	45	MuteGuitar
16	Digi Piano	26	Xylophon	36	Musette	46	Over Drive
17	Harpsicord	27	Tubular	37	Harmonica	47	DistGuitar
18	Clav	28	Santur	38	Tango	48	RockMonics
51	Jazz Bass	61	Violin	71	Marcato	81	Trumpet
52	Deep Bass	62	Viola	72	SlowString	82	Trombone 1
53	Pick Bass	63	Cello	73	Analog Pad	83	Tuba
54	Fretless	64	ContraBass	74	String Pad	84	Muted Trpt
55	SlapBass 1	65	TremoloStr	75	Choir	85	FrenchHorn
56	SlapBass 2	66	Pizzicato	76	Doo Voice	86	Brass
57	SynthBass1	67	Harp	77	Voices	87	SynBrass 1
58	SynthBass2	68	Timpani	78	Orch Hit	88	SynBrass 2

Bank B (General MIDI)

11	SopranoSax	21	Piccolo	31	SquareWave	41	Fantasia
12	Alto Sax	22	Flute	32	Saw Wave	42	Warm Pad
13	Tenor Sax	23	Recorder	33	SynCaliope	43	Poly Pad
14	Bari Sax	24	Pan Flute	34	Syn Chiff	44	Ghost Pad
15	Sweet Oboe	25	Bottle	35	Charang	45	BowedGlas
16	EnglishHrn	26	Shakuhachi	36	AirChorus	46	Metal Pad
17	BasoonOboe	27	Whistle	37	Rezzo4ths	47	Halo Pad
18	Clarinet	28	Ocarina	38	Bass&Lead	48	Sweep
51	Ice Rain	61	Sitar	71	Metal Bell	81	Fret Noise
52	SoundTrack	62	Banjo	72	Agogo	82	NoiseChiff
53	Crystal	63	Shamisen	73	SteelDrums	83	Seashore
54	Atmosphere	64	Koto	74	Woodblock	84	Birds
55	Brightness	65	Kalimba	75	Taiko	85	Telephone
56	Goblin	66	Scotland	76	Tom	86	Helicopter
57	Echo Drop	67	Fiddle	77	Synth Tom	87	Stadium!!
58	Star Theme	68	Shanai	78	Rev Cymbal	88	GunShot

Bank C

11	MIDI Piano	21	60's Organ	31	L&R A.Gtrs	41	Strummers
12	Pad Piano	22	Gospel Org	32	ElectricAc	42	E. Guitars
13	Fresh Air	23	HamN Cheese	33	PedalSteel	43	L&R E.Gtrs
14	Piano&Str	24	Perc&Rotor	34	Harmonics	44	Dirty Funk
15	Hard Tines	25	Akordeon 1	35	HollowBody	45	DirtyMutes
16	DigiPiano2	26	Akordeon 2	36	PickedMute	46	DistoMutes
17	Whirly	27	Hackbrett	37	Funky Gtr	47	StereoDist
18	HousePiano	28	Mando Trem	38	Clean Funk	48	PowerChord
51	WoodBass	61	StringOct	71	FluteClar	81	Euro Bass
52	DiscoBass	62	Analog Pad	72	Clarn Ens	82	House Bass
53	Funk Bass	63	i3 Strings	73	PerkySaxes	83	Rap Bass
54	PickBass 2	64	AirVoxDbl	74	Mute Ens.	84	TubaShort
55	Bass/Mute	65	Airways	75	BriteBones	85	SynBrass 3
56	Gtr/Bass	66	The Voices	76	Trumpets!!	86	Comp Thing
57	SlapBass 3	67	BellPad	77	Tromb Ens	87	Lead Stab
58	Deep Slap	68	SynPad	78	Brass Band	88	Metal Clav

Bank D

11	Piano 8' (i2 Piano)	21	Drawbars	31	Vibra Bell	41	AltoBreath
12	MaxiTine	22	TheaterOrg	32	Gamelan	42	FlugelHorn
13	Tap EP	23	Hot Keys	33	SplitBell	43	Trombones!
14	Elec. Tap	24	VS Organ	34	Isabelle	44	Air Flute
15	Operators	25	HarpsiFunk	35	JewelryBox	45	Woodwinds
16	VS EP	26	Full Pipes	36	VS Bells	46	Sfz< Brass
17	Express EP	27	Last Tango	37	AfricanJam	47	Fanfare
18	BrassOrg	28	Fisa 8'	38	SolarBells	48	Pan mallet
51	Poppin'Pad	61	Shaku Bend	71	RaveBass 1	81	Space Pets
52	TheStrings	62	Nay	72	SweepBass	82	SteamCloud
53	AnaSyn	63	Kanoun	73	Dr.Bass	83	RaveVox
54	Pitzpan	64	Aoud	74	RaveBass 2	84	50's SciFi
55	PhaseSynth	65	Mizmar	75	Bass Solo	85	DJ Kit 1
56	Analogist	66	Bouzouki	76	Leeeed	86	Space Wing
57	Color Pad	67	Uood	77	Busy Boy	87	GlideSweep
58	PowerSynth	68	Sitar 2	78	MonoLead	88	Sunrise

Bank Dr

1	GM Kit	3	Analog Kit	5	Brush Kit	7	Dance Kit
2	Power Kit	4	Jazz Kit	6	Perc Kit	8	Orch Kit

i2/i3 Multisound List

0	A.Piano 1	33	PipeOrg2LP	66	PowerChd V	99	SynthBass1	132	Ocarina
1	A.Piano1LP	34	PipeOrgan3	67	OverDvChrd	100	SynBass1LP	133	Oboe
2	A.Piano 2	35	PipeOrg3LP	68	Gtr Slide	101	SynthBass2	134	EnglishHrn
3	E.Piano 1	36	Musette	69	GtrSlide V	102	SynBass2LP	135	Eng.HornLP
4	E.Piano1LP	37	Musette V	70	Sitar 1	103	House Bass	136	BasoonOboe
5	E.Piano 2	38	Bandneon	71	Sitar 2	104	FM Bass	137	BsonOboeLP
6	E.Piano2LP	39	BandneonLP	72	Sitar 2 LP	105	FM Bass LP	138	Clarinet
7	Soft EP	40	Accordion	73	Santur	106	Kalimba	139	ClarinetLP
8	Soft EP LP	41	AcordionLP	74	Bouzouki	107	Music Box	140	Bari Sax
9	Hard EP	42	Harmonica	75	BouzoukiLP	108	MusicBoxLP	141	Bari SaxLP
10	Hard EP LP	43	G.Guitar	76	Banjo	109	Log Drum	142	Tenor Sax
11	PianoPad 1	44	G.GuitarLP	77	Shamisen	110	Marimba	143	T.Sax LP
12	PianoPad 2	45	F.Guitar	78	Koto	111	Xylophone	144	Alto Sax
13	Clav	46	F.GuitarLP	79	Uood	112	Vibe	145	A.Sax LP
14	Clav LP	47	F.Guitar V	80	Harp	113	Celesta	146	SopranoSax
15	Harpsicord	48	A.Gtr Harm	81	MandlnTrm	114	Glocken	147	S.Sax LP
16	HarpsicdLP	49	E.Guitar 1	82	A.Bass 1	115	BrightBell	148	Tuba
17	PercOrgan1	50	E.Guitr1 V	83	A.Bass1 LP	116	B.Bell LP	149	Tuba LP
18	PercOrg1LP	51	E.Guitar 2	84	A.Bass 2	117	Metal Bell	150	Horn
19	PercOrgan2	52	E.Guitar 3	85	A.Bass2 LP	118	M.Bell LP 1	151	FlugelHorn
20	PercOrg2LP	53	MuteGuitar	86	E.Bass 1	119	Gamelan	152	Trombone 1
21	Organ 1	54	Funky Gtr	87	E.Bass1 LP	120	Pole	153	Trombone 2
22	Organ 1 LP	55	FunkyGtr V	88	E.Bass 2	121	Pole LP	154	Trumpet
23	Organ 2	56	E.Gtr Harm	89	E.Bass2 LP	122	Tubular	155	Trumpet LP
24	Organ 2 LP	57	DistGuitar	90	Pick Bass1	123	Split Drum	156	Mute TP
25	Organ 3	58	DistGtrLP	91	PicBass1LP	124	Split Bell	157	Mute TP LP
26	Organ 4	59	DistGuitrV	92	Pick Bass2	125	Flute	158	Brass 1
27	Organ 5	60	Over Drive	93	Fretless	126	Pan Flute	159	Brass 1 LP
28	RotaryOrg1	61	OverDrv LP	94	FretlessLP	127	PanFlutelP	160	Brass 2
29	RotaryOrg2	62	OverDrv F4	95	Slap Bass1	128	Shakuhachi	161	Brass 2 LP
30	PipeOrgan1	63	MuteDstGtr	96	Slap Bass2	129	ShakhachLP	162	StringEns.
31	PipeOrg1LP	64	MtDstGtr V	97	SlpBass2LP	130	Bottle	163	StrEns. V1
32	PipeOrgan2	65	PowerChord	98	Slap Bass3	131	Recorder	164	StrEns. V2

165 StrEns. V3	201 Clicker NT	237 Splash Cym	273 Hand Clap	309 Guiro LP
166 AnaStrings	202 Crickets 1	238 Orch Crash	274 HandClapNT	310 Scratch Hi
167 PWM	203 Crickets1NT	239 Tite HH	275 Gun Shot	311 ScratchHiNT
168 Violin	204 Crickets 2	240 Tite HH NT	276 Castanet	312 Scratch Lo
169 Cello	205 Crickets2NT	241 Bell Ride	277 CastanetNT	313 ScratchLoNT
170 Cello LP	206 Magic Bell	242 Ping Ride	278 Snap	314 ScratchDbI
171 Pizzicato	207 Sporing	243 Timpani	279 Snap NT	315 ScratchDbINT
172 Voice	208 Rattle	244 Timpani LP	280 Gt Scratch	316 Mini 1a
173 Choir	209 Kava 1	245 Cabasa	281 Side Stick	317 Digital 1
174 Soft Choir	210 Kava 2	246 Cabasa NT	282 SideStikNT	318 VS 102
175 Air Vox	211 Fever 1	247 Agogo	283 TimbleSide	319 VS 48
176 Doo Voice	212 Fever 2	248 Cow Bell	284 TimblSidNT	320 VS 52
177 DooVoiceLP	213 Zappers 1	249 Low Bongo	285 Syn Rim	321 VS 58
178 Syn Vox	214 Zappers 2	250 Claves	286 Syn Rim NT	322 VS 71
179 Syn Vox LP	215 Bugs	251 Timbale	287 Open HH	323 VS 72
180 White Pad	216 Surty	252 WoodBlock1	288 OpenSyn HH	324 VS 88
181 Ether Bell	217 SleighBell	253 WoodBlock2	289 CloseSynHH	325 VS 89
182 E.Bell LP	218 Elec Beat	254 WoodBlock3	290 Sagat	326 13 - 35
183 Mega Pad	219 Idling	255 Taiko Hit	291 Sagat NT	327 DWGSOrgan1
184 Spectrum 1	220 EthnicBeat	256 Syn Claves	292 Sagatty	328 DWGSOrgan2
185 Spectrum 2	221 Taps	257 Melo Tom	293 Sagatty NT	329 DWGS E.P.
186 Stadium	222 Tap 1	258 ProccesTom	294 JingleBell	330 Saw
187 Stadium NT	223 Tap 2	259 Syn Tom 1	295 Taiko	331 Square
188 BrushNoise	224 Tap 3	260 Syn Tom 2	296 Slap Bongo	332 Ramp
189 BruNoiseNT	225 Tap 4	261 VocalSnare	297 Open Conga	333 Pulse 25%
190 Steel Drum	226 Tap 5	262 Zap 1	298 Slap Conga	334 Pulse 8%
191 SteelDrmLP	227 Orch Hit	263 Zap 2	299 Palm Conga	335 Pulse 4%
192 BrushSwirl	228 SnareRI/Ht	264 Fret Zap 1	300 Mute Conga	336 Syn Sine
193 Belltree	229 Syn Snare	265 Fret Zap 2	301 Tabla 1	337 Sine
194 BelltreeNT	230 Rev Snare	266 Vibra Slap	302 Tabla 2	338 DJ Kit 1
195 BeltreV NT	231 PowerSnare	267 Indust	303 Maracas	339 DJ Kit 2
196 Tri Roll	232 Orch Perc	268 Thing	304 SynMaracas	340 A.Piano.3 *
197 TriRoll NT	233 Crash Cym	269 Thing NT	305 SynMarcsNT	
198 Telephon	234 CrashCymLP	270 FingerSnap	306 MuteTriang	
199 TelephonNT	235 CrashLP NT	271 FingSnapNT	307 OpenTriang	* i2 only
200 Clicker	236 China Cym	272 Tambourne	308 Guiro	

i2/i3 Drum Sound List

0	Fat Kick	33	BrushSwish	66	Lo Bongo	99	Scratch Lo	132	Vibe 2
1	Rock Kick	34	BrushSwirl	67	Hi Bongo	100	ScratchDb1	133	Vibe 3
2	Ambi.Kick	35	Brush Tap	68	Slap Bongo	101	Thing	134	Vibe 4
3	Crisp Kick	36	Side Stick	69	Claves	102	Mute Cuica	135	Pole
4	Punch Kick	37	Syn Rim	70	Syn Claves	103	Open Cuica	136	TubulBell1
5	Real Kick	38	VocalSnr 1	71	Open Conga	104	Vibraslap	137	TubulBell2
6	Dance Kick	39	VocalSnr 2	72	Slap Conga	105	Guiro S	138	TubulBell3
7	Gated Kick	40	Crash Cym	73	Palm Conga	106	Guiro L	139	Gt Scratch
8	ProcesKick	41	Crash LP	74	Mute Conga	107	Castanet	140	Chic 1
9	Metal Kick	42	China Cym	75	Baya 1	108	FingerSnap	141	Chic 2
10	Syn Kick 1	43	China LP	76	Baya 2	109	Timbales	142	Spectrum 1
11	Syn Kick 2	44	Splash Cym	77	Tabla 1	110	Kalimba 1	143	Spectrum 2
12	Syn Kick 3	45	Splash LP	78	Tabla 2	111	Kalimba 2	144	Stadium
13	Orch B.Drm	46	Orch Crash	79	Tabla 3	112	Marimba 1	145	BrushNoise
14	Snare 1	47	OrchCym LP	80	Maracas	113	Marimba 2	146	Gt Slide
15	Snare 2	48	Tite HH	81	Cabasa	114	Marimba 3	147	Bell Tree
16	Snare 3	49	Open HH	82	SynMaracas	115	Marimba 4	148	Tri Roll
17	Snare 4	50	Pedal HH	83	MuteTriang	116	Xylofon 1	149	JingleBell
18	PicloSnare	51	CloseSynHH	84	OpenTriang	117	Xylofon 2	150	Whistle S
19	Soft Snare	52	Open SynHH	85	Tambourine	118	Xylofon 3	151	Whistle L
20	LightSnare	53	Sagat	86	Cowbell	119	Log Drum 1	152	Timpani
21	TightSnare	54	Ride Edge	87	SynCowbell	120	Log Drum 2	153	Taiko Hi
22	Ambi.Snare	55	Ride Cup	88	R-Timbal	121	Log Drum 3	154	Taiko Lo
23	Rev Snare	56	Ride Cym 1	89	Hi Timbal	122	Log Drum 4	155	Music Box1
24	RollSnare1	57	Ride Cym 2	90	Lo Timbal	123	Log Drum 5	156	Music Box2
25	RollSnare2	58	Tom Hi	91	WoodBlock1	124	Snap	157	Clicker 1
26	Rock Snare	59	Tom Lo	92	WoodBlock2	125	BrightBell	158	Clicker 2
27	GatedSnare	60	ProcessTom	93	WoodBlock3	126	Metal Bell	159	Clicker 3
28	PowerSnare	61	SynTom1 Hi	94	Hand Claps	127	Gamelan 1	160	Crickets
29	Syn Snare1	62	SynTom1 Lo	95	Syn Claps	128	Gamelan 2	161	Orch Hit
30	Syn Snare2	63	Syn Tom 2	96	Zap 1	129	Celeste	162	Metronome1
31	Gun Shot	64	Brush Tom	97	Zap 2	130	Glocken	163	Metronome
32	Brush Slap	65	Agogo	98	Scratch Hi	131	Vibe 1		

Drum Kit Layout

	1: Dance Kit		2: Orch Kit		3: GM Standard		4: Power Kit		
	Drum Sound	Ex.group	Drum Sound	Ex.group	Drum Sound	Ex.group	Drum Sound	Ex.group	
	27	•	•	48 Tite HH	EX1	•	•	•	•
C2	28	3 Crisp Kick	Off	50 Pedal HH	EX1	1 Rock Kick	Off	2 Ambi.Kick	Off
	29	18 PicloSnare	Off	49 Open HH	EX1	16 Snare 3	EX6	26 Rock Snare	Off
	30	49 Open HH	EX1	54 Ride Edge	Off	49 Open HH	EX1	49 Open HH	EX1
	31	11 Syn Kick 2	Off	•	•	0 Fat Kick	Off	7 Gated Kick	Off
	32	36 Side Stick	Off	•	•	109 Timbales	Off	109 Timbales	Off
	33	21 TightSnare	Off	•	•	14 Snare 1	EX6	21 TightSnare	Off
	34	23 Rev Snare	Off	•	•	24 RollSnare1	EX6	23 Rev Snare	Off
	35	2 Ambi.Kick	Off	5 Real Kick	Off	5 Real Kick	Off	7 Gated Kick	Off
	36	6 Dance Kick	Off	13 Orch B.Drm	Off	8 ProcesKick	Off	9 Metal Kick	Off
	37	36 Side Stick	Off	36 Side Stick	Off	36 Side Stick	Off	36 Side Stick	Off
	38	30 Syn Snare2	Off	25 RollSnare2	Off	26 Rock Snare	EX6	28 PowerSnare	Off
	39	94 Hand Claps	Off	107 Castanet	Off	94 Hand Claps	Off	94 Hand Claps	Off
	40	22 Ambi.Snare	Off	25 RollSnare2	Off	20 LightSnare	EX6	27 GatedSnare	Off
	41	60 ProcessTom	Off	•	•	59 Tom Lo	Off	60 ProcessTom	Off
	42	48 Tite HH	EX1	•	•	48 Tite HH	EX1	48 Tite HH	EX1
	43	60 ProcessTom	Off	•	•	59 Tom Lo	Off	60 ProcessTom	Off
	44	50 Pedal HH	EX1	•	•	50 Pedal HH	EX1	50 Pedal HH	EX1
	45	60 ProcessTom	Off	•	•	59 Tom Lo	Off	60 ProcessTom	Off
	46	49 Open HH	EX1	•	•	49 Open HH	EX1	49 Open HH	EX1
	47	60 ProcessTom	Off	•	•	58 Tom Hi	Off	60 ProcessTom	Off
C3	48	60 ProcessTom	Off	•	•	58 Tom Hi	Off	60 ProcessTom	Off
	49	40 Crash Cym	Off	•	•	40 Crash Cym	Off	40 Crash Cym	Off
	50	60 ProcessTom	Off	•	•	58 Tom Hi	Off	60 ProcessTom	Off
	51	54 Ride Edge	Off	•	•	54 Ride Edge	Off	54 Ride Edge	Off
	52	42 China Cym	Off	•	•	42 China Cym	Off	42 China Cym	Off
	53	55 Ride Cup	Off	152 Timpani	Off	55 Ride Cup	Off	55 Ride Cup	Off
	54	85 Tambourine	Off	85 Tambourine	Off	85 Tambourine	Off	85 Tambourine	Off
	55	44 Splash Cym	Off	44 Splash Cym	Off	44 Splash Cym	Off	44 Splash Cym	Off
	56	86 Cowbell	Off	86 Cowbell	Off	86 Cowbell	Off	86 Cowbell	Off
	57	40 Crash Cym	Off	40 Crash Cym	Off	40 Crash Cym	Off	40 Crash Cym	Off
	58	104 Vibraslap	Off	104 Vibraslap	Off	104 Vibraslap	Off	104 Vibraslap	Off
	59	54 Ride Edge	Off	46 Orch Crash	Off	56 Ride Cym 1	Off	56 Ride Cym 1	Off
C4	60	67 Hi Bongo	Off	67 Hi Bongo	Off	67 Hi Bongo	Off	67 Hi Bongo	Off
	61	66 Lo Bongo	Off	66 Lo Bongo	Off	66 Lo Bongo	Off	66 Lo Bongo	Off
	62	74 Mute Conga	Off	74 Mute Conga	Off	74 Mute Conga	Off	74 Mute Conga	Off
	63	71 Open Conga	Off	71 Open Conga	Off	71 Open Conga	Off	71 Open Conga	Off
	64	71 Open Conga	Off	71 Open Conga	Off	71 Open Conga	Off	71 Open Conga	Off
	65	89 Hi Timbal	Off	89 Hi Timbal	Off	89 Hi Timbal	Off	89 Hi Timbal	Off
	66	90 Lo Timbal	Off	90 Lo Timbal	Off	90 Lo Timbal	Off	90 Lo Timbal	Off
	67	65 Agogo	Off	65 Agogo	Off	65 Agogo	Off	65 Agogo	Off
	68	65 Agogo	Off	65 Agogo	Off	65 Agogo	Off	65 Agogo	Off
	69	81 Cabasa	Off	81 Cabasa	Off	81 Cabasa	Off	81 Cabasa	Off
	70	80 Maracas	Off	80 Maracas	Off	80 Maracas	Off	80 Maracas	Off
	71	150 Whistle S	EX2	150 Whistle S	EX2	150 Whistle S	EX2	150 Whistle S	EX2
C5	72	151 Whistle L	EX2	151 Whistle L	EX2	151 Whistle L	EX2	151 Whistle L	EX2
	73	105 Guiro S	EX3	105 Guiro S	EX3	105 Guiro S	EX3	105 Guiro S	EX3
	74	106 Guiro L	EX3	106 Guiro L	EX3	106 Guiro L	EX3	106 Guiro L	EX3
	75	69 Claves	Off	69 Claves	Off	69 Claves	Off	69 Claves	Off
	76	92 WoodBlock2	Off	92 WoodBlock2	Off	92 WoodBlock2	Off	92 WoodBlock2	Off
	77	93 WoodBlock3	Off	93 WoodBlock3	Off	93 WoodBlock3	Off	93 WoodBlock3	Off
	78	102 Mute Cuica	EX4	102 Mute Cuica	EX4	102 Mute Cuica	EX4	102 Mute Cuica	EX4
	79	103 Open Cuica	EX4	103 Open Cuica	EX4	103 Open Cuica	EX4	103 Open Cuica	EX4
	80	83 MuteTriang	EX5	83 MuteTriang	EX5	83 MuteTriang	EX5	83 MuteTriang	EX5
	81	84 OpenTriang	EX5	84 OpenTriang	EX5	84 OpenTriang	EX5	84 OpenTriang	EX5
	82	81 Cabasa	Off	81 Cabasa	Off	81 Cabasa	Off	81 Cabasa	Off
	83	149 JingleBell	Off	149 JingleBell	Off	149 JingleBell	Off	149 JingleBell	Off
C6	84	147 Bell Tree	Off	147 Bell Tree	Off	147 Bell Tree	Off	147 Bell Tree	Off
	85	107 Castanet	Off	107 Castanet	Off	107 Castanet	Off	107 Castanet	Off
	86	36 Side Stick	Off	36 Side Stick	Off	36 Side Stick	Off	36 Side Stick	Off
	87	154 Taiko Lo	Off	154 Taiko Lo	Off	154 Taiko Lo	Off	154 Taiko Lo	Off

		5: Analog Kit		6: Jazz Kit		7: Brush Kit		8: Percussion Kit	
		Drum Sound	Ex.group	Drum Sound	Ex.group	Drum Sound	Ex.group	Drum Sound	Ex.group
	28	12 Syn Kick 3	Off	3 Crisp Kick	Off	3 Crisp Kick	Off	67 Hi Bongo	Off
	29	30 Syn Snare2	Off	17 Snare 4	EX6	108 FingerSnap	EX6	66 Lo Bongo	Off
	30	52 Open SynHH	EX1	49 Open HH	EX1	49 Open HH	EX1	85 Tambourine	Off
	31	6 Dance Kick	Off	2 Ambi.Kick	Off	2 Ambi.Kick	Off	65 Agogo	Off
	32	109 Timbales	Off	109 Timbales	Off	109 Timbales	Off	38 VocalSnr 1	Off
	33	22 Ambi.Snare	Off	25 RollSnare2	EX6	32 Brush Slap	EX6	65 Agogo	Off
	34	23 Rev Snare	Off	24 RollSnare1	EX6	24 RollSnare1	EX6	68 Slap Bongo	Off
	35	3 Crisp Kick	Off	4 Punch Kick	Off	4 Punch Kick	Off	93 WoodBlock3	Off
C2	36	10 Syn Kick 1	Off	1 Rock Kick	Off	1 Rock Kick	Off	69 Claves	Off
	37	37 Syn Rim	Off	36 Side Stick	Off	36 Side Stick	Off	92 WoodBlock2	Off
	38	29 Syn Snare1	Off	19 Soft Snare	EX6	35 Brush Tap	EX6	86 Cowbell	Off
	39	95 Syn Claps	Off	94 Hand Claps	Off	32 Brush Slap	Off	91 WoodBlock1	Off
	40	20 LightSnare	Off	15 Snare 2	EX6	33 BrushSwish	Off	107 Castanet	Off
	41	62 SynTom1 Lo	Off	59 Tom Lo	Off	64 Brush Tom	Off	76 Baya 2	Off
	42	51 CloseSynHH	EX1	48 Tite HH	EX1	48 Tite HH	EX1	81 Cabasa	Off
	43	62 SynTom1 Lo	Off	59 Tom Lo	Off	64 Brush Tom	Off	75 Baya 1	Off
	44	51 CloseSynHH	EX1	50 Pedal HH	EX1	50 Pedal HH	EX1	80 Maracas	Off
	45	62 SynTom1 Lo	Off	59 Tom Lo	Off	64 Brush Tom	Off	76 Baya 2	Off
	46	52 Open SynHH	EX1	49 Open HH	EX1	49 Open HH	EX1	81 Cabasa	Off
	47	62 SynTom1 Lo	Off	58 Tom Hi	Off	64 Brush Tom	Off	79 Tabla 3	EX1
C3	48	62 SynTom1 Lo	Off	58 Tom Hi	Off	64 Brush Tom	Off	78 Tabla 2	EX1
	49	52 Open SynHH	Off	40 Crash Cym	Off	40 Crash Cym	Off	104 Vibraslap	Off
	50	62 SynTom1 Lo	Off	58 Tom Hi	Off	64 Brush Tom	Off	77 Tabla 1	EX1
	51	54 Ride Edge	Off	57 Ride Cym 2	Off	57 Ride Cym 2	Off	83 MuteTriang	EX3
	52	42 China Cym	Off	42 China Cym	Off	42 China Cym	Off	13 Orch B.Drm	Off
	53	55 Ride Cup	Off	56 Ride Cym 1	Off	56 Ride Cym 1	Off	84 OpenTriang	EX3
	54	85 Tambourine	Off	85 Tambourine	Off	85 Tambourine	Off	105 Guiro S	EX2
	55	44 Splash Cym	Off	44 Splash Cym	Off	44 Splash Cym	Off	149 JingleBell	Off
	56	87 SynCowbell	Off	86 Cowbell	Off	86 Cowbell	Off	106 Guiro L	EX2
	57	40 Crash Cym	Off	40 Crash Cym	Off	40 Crash Cym	Off	147 Bell Tree	Off
	58	104 Vibraslap	Off	104 Vibraslap	Off	104 Vibraslap	Off	101 Thing	Off
	59	56 Ride Cym 1	Off	54 Ride Edge	Off	54 Ride Edge	Off	80 Maracas	Off
C4	60	67 Hi Bongo	Off	67 Hi Bongo	Off	67 Hi Bongo	Off	94 Hand Claps	Off
	61	66 Lo Bongo	Off	66 Lo Bongo	Off	66 Lo Bongo	Off	95 Syn Claps	Off
	62	61 SynTom1 Hi	Off	74 Mute Conga	Off	74 Mute Conga	Off	99 Scratch Lo	Off
	63	61 SynTom1 Hi	Off	71 Open Conga	Off	71 Open Conga	Off	98 Scratch Hi	Off
	64	61 SynTom1 Hi	Off	71 Open Conga	Off	71 Open Conga	Off	100 ScratchDbl	Off
	65	89 Hi Timbal	Off	89 Hi Timbal	Off	89 Hi Timbal	Off	150 Whistle S	EX4
	66	90 Lo Timbal	Off	90 Lo Timbal	Off	90 Lo Timbal	Off	151 Whistle L	EX4
	67	65 Agogo	Off	65 Agogo	Off	65 Agogo	Off	72 Slap Conga	Off
	68	65 Agogo	Off	65 Agogo	Off	65 Agogo	Off	74 Mute Conga	Off
	69	81 Cabasa	Off	81 Cabasa	Off	81 Cabasa	Off	71 Open Conga	Off
	70	82 SynMaracas	Off	80 Maracas	Off	80 Maracas	Off	71 Open Conga	Off
	71	150 Whistle S	EX2	150 Whistle S	EX2	150 Whistle S	EX2	102 Mute Cuica	Off
C5	72	151 Whistle L	EX2	151 Whistle L	EX2	151 Whistle L	EX2	103 Open Cuica	Off
	73	105 Guiro S	EX3	105 Guiro S	EX3	105 Guiro S	EX3	109 Timbales	Off
	74	106 Guiro L	EX3	106 Guiro L	EX3	106 Guiro L	EX3	88 R-Timbal	Off
	75	70 Syn Claves	Off	69 Claves	Off	69 Claves	Off	89 Hi Timbal	Off
	76	92 WoodBlock2	Off	92 WoodBlock2	Off	92 WoodBlock2	Off	90 Lo Timbal	Off
	77	93 WoodBlock3	Off	93 WoodBlock3	Off	93 WoodBlock3	Off	70 Syn Claves	Off
	78	102 Mute Cuica	EX4	102 Mute Cuica	EX4	102 Mute Cuica	EX4	87 SynCowbell	Off
	79	103 Open Cuica	EX4	103 Open Cuica	EX4	103 Open Cuica	EX4	108 FingerSnap	Off
	80	83 MuteTriang	EX5	83 MuteTriang	EX5	83 MuteTriang	EX5	153 Taiko Hi	Off
	81	84 OpenTriang	EX5	84 OpenTriang	EX5	84 OpenTriang	EX5	154 Taiko Lo	Off
	82	81 Cabasa	Off	81 Cabasa	Off	81 Cabasa	Off	97 Zap 2	Off
	83	149 JingleBell	Off	149 JingleBell	Off	149 JingleBell	Off	24 RollSnare1	EX5
C6	84	147 Bell Tree	Off	147 Bell Tree	Off	147 Bell Tree	Off	25 RollSnare2	EX5
	85	107 Castanet	Off	107 Castanet	Off	107 Castanet	Off	46 Orch Crash	EX6
	86	36 Side Stick	Off	36 Side Stick	Off	36 Side Stick	Off	46 Orch Crash	EX6
	87	154 Taiko Lo	Off	154 Taiko Lo	Off	154 Taiko Lo	Off	.	.
	104							.	.
A7	105							161 Orch Hit	Off

ディスクファイルの管理

i2/i3はMS-DOSディスクフォーマットを使用しているため、ディスクファイルを整理するときに何の制約もありません。あなたが頻繁に使用するのがアレンジメントであるならば、アレンジメントファイルだけが入ったディスクを用意することができます。ファイルは比較的小さいので(約9キロバイト)、1枚のディスクにかなりの数が入ります。

あなたのスタイルを作成したら、「マスター」のアレンジメントファイルを作成してスタイルファイルと共に使用することができます(各アレンジメントファイルには64のアレンジメントがありますが、各スタイルファイルには4つのスタイルしかありませんのでご注意ください)。

i2/i3を使いこなしていくにつれて、あなたに一番適した方法が見つかることでしょう。

*MS-DOSは米国マイクロソフト社の登録商標です。

X3データとの互換性

コルグX3ミュージックワークステーションはi2/i3と同じプログラム、ソング構成をしています。ディスクフォーマットが同じなので、X3のディスクからプログラムやソングを直接i2/i3にロードすることができます。同様に、i2/i3のディスクからX3にプログラムやソングを直接ロードすることも可能です。

プログラムは下記のプログラムロケーションにロードされます。

X3 Programs		i2/i3 Programs
A00-A63	↔	D11-D88
A64-A65	↔	Dr7-Dr8

ソングトラックのプログラムチェンジイベントは次のように変換されます。

X3		i2/i3
GM1-GM64	↔	A11-A88
GM65-GM128	↔	B11-B88
B00-B63	↔	C11-C88
A00-A63	↔	D11-D88
A64-A65	↔	Dr7-Dr8

i2をお使いの方へ:

i2にはプログラムA11 PianoとD11 i2 Pianoで使われているピアノマルチサウンドが追加されています。プログラムD11はRAMにあるため、誤って消去したり書き換えてしまう可能性があります。たとえば、“AMERICA”ファイルを開いたり、デモ・バックギンシーケンスにするためロードすると、i2 Pianoプログラムが“AMERICA.PCG”ファイルの8' Pianoプログラムに書き換えられてしまいます(プログラムA11とマルチサウンド340は共にROMにありますので、消去はできません)。

i2 PianoプログラムをリストアするためにIFD-00Pファクトリーディスクに“_I2DBANK.PCG”ファイルがあります。このファイルはD11 i2 Pianoプログラムを除いて“AMERICA.PCG”ファイルと同じプログラムが入っています。ロードオールプログラム機能かロードワンプログラム機能を使ってこのプログラムのリストアをしてください。

KORG KORG INC.

15 - 12, Shimotakaido 1 - chome, Suginami-ku, Tokyo, Japan.