

SQ-64 System Firmware Update


Update Procedures

- 🔊 This updater is compatible with Windows 8.1 or later.
- 🔊 The latest "KORG USB-MIDI Driver" needs to be installed before the update.
If the driver installed on your computer is older than the latest version, install the latest version of the driver before starting the update. (<http://www.korg.com>)
- 🔊 Do not operate the SQ-64 or the computer during the update process.
- 🔊 Close all other applications before running the updater.
- 🔊 After updating, do not downgrade to a previous system version. The operation of a downgraded unit will not be guaranteed.


1. Unzip the " SQ_64_Updater_????_win.zip ". (???? is version number)

- 🔊 Extract all the files in the zip file before proceeding to the next step. The updater may not be able to find necessary files if they were not unzipped.

2. Connect the SQ-64 to a computer using a USB cable, then boot the SQ-64 in update mode. Turn on the SQ-64 holding the [GLOBAL] and [PATTERN] buttons. This will enter the version upgrade mode.




3. Execute the "kmupdate.exe". The following window will appear.




4. Push the Update button in the window to start the process.

▲ If the following message is shown, the system firmware is already up to date, and no change is needed. In this case simply quit the KORG System Updater.




▲ If an "Error message" is shown, confirm that the SQ-64 is connected to the computer properly, or that the latest version of the "KORG USB-MIDI Driver" has already been installed.

5. During the updating process, the following window will appear. The whole process might take several minutes to complete.



 **Do not turn off the SQ-64 during the update process.**

6. The following message will be shown when the update has successfully completed. This will conclude the entire update procedure.



Quit the KORG System Updater, and turn off the SQ-64.