

Programs - "M1" Bonus Sound Library for KROME

Bank F

#	Name	Category	Sub Category	OSC Mode
I-F000	Universe	MotionSynth	Motion	D
I-F001	Piano 16'	Keyboard	A.Piano	S
I-F002	Brass 1	Brass	Ensemble	S
I-F003	Ooh/Ahh	Vocal/Airy	Vocal	S
I-F004	Guitar 1	Guitar/Plucked	A.Guitar	S
I-F005	BottleBell	Bell/Mallet	Bell	D
I-F006	Fretless	Bass/Synth Bass	E.Bass	S
I-F007	Symphonic	Strings	Ensemble	D
I-F008	Pan Flute	Woodwind/Reed	Woodwind	S
I-F009	Drums #1	Drums	Natural Drums	S
I-F010	PanMallet	FastSynth	Short Release	D
I-F011	E.Piano 1	Keyboard	Synth E.Piano	S
I-F012	Trumpet	Brass	Solo	S
I-F013	Nimbus	MotionSynth	Motion	D
I-F014	DistGuitar	Guitar/Plucked	E.Guitar	D
I-F015	Vibes	Bell/Mallet	Mallet	S
I-F016	Pick Bass	Bass/Synth Bass	E.Bass	D
I-F017	Organ 2	Organ	E.Organ	S
I-F018	Flute	Woodwind/Reed	Woodwind	S
I-F019	Pole	Short Decay/Hit	Hit	S
I-F020	Dream Pad	SlowSynth	Bright	D
I-F021	MagicPiano	Keyboard	Synth E.Piano	D
I-F022	Solo Sax	Woodwind/Reed	Reed	S
I-F023	Choir	Vocal/Airy	Vocal	S
I-F024	12-String	Guitar/Plucked	A.Guitar	D
I-F025	Kalimba	Bell/Mallet	Mallet	S
I-F026	A.Bass	Bass/Synth Bass	A.Bass	S
I-F027	Strings	Strings	Ensemble	S
I-F028	SynMallet	Bell/Mallet	Mallet	S
I-F029	Drums #2	Drums	Natural Drums	S
I-F030	Lore	SFX	Synthetic	S
I-F031	Harpsicord	Keyboard	Clav/Harpsi	S
I-F032	Doublereed	Woodwind/Reed	Reed	S
I-F033	Bottles	Woodwind/Reed	Woodwind	S
I-F034	Koto Trem	MotionSynth	Motion	S
I-F035	Bell Ring	MotionSynth	Motion	S
I-F036	SynthBass1	Bass/Synth Bass	Synth Bass	S
I-F037	Timp&Bells	Bell/Mallet/Bell	Bell	D
I-F038	Solo Synth	LeadSynth	Hard	S
I-F039	Pop	Short Decay/Hit	Short Decay	S
I-F040	Magician	MotionSynth	Motion	D
I-F041	Piano 8'	Keyboard	A.Piano	S
I-F042	Overture	Brass	Ensemble	D
I-F043	Angels	Vocal/Airy	Airy	D
I-F044	Sitar 1	Guitar/Plucked	Plucked	S
I-F045	Tubular	Bell/Mallet	Bell	S
I-F046	Slap Bass	Bass/Synth Bass	E.Bass	S
I-F047	Pipe Organ	Organ	Pipe Organ	S
I-F048	Wire	FastSynth	Short Release	S
I-F049	Drums #3	Drums	Natural Drums	S
I-F050	Bambu Trem	MotionSynth	Motion	S
I-F051	E.Piano 4	Keyboard	Synth E.Piano	S
I-F052	TubaFlugel	Brass	Solo	S
I-F053	Voice Wave	Vocal/Airy	Vocal	S
I-F054	Guitar 2	Guitar/Plucked	A.Guitar	S
I-F055	Metal Hit	Short Decay/Hit	Hit	S
I-F056	SynthBass2	Bass/Synth Bass	Synth Bass	S
I-F057	StringsRise	MotionSynth	Motion	D
I-F058	Pan Wave	FastSynth	Short Release	S
I-F059	Hammer	Short Decay/Hit	Hit	S
I-F060	Cloud Nine	SlowSynth	Dark	D
I-F061	Clav	Keyboard	Clav/Harpsi	S
I-F062	Tenor Sax	Woodwind/Reed	Reed	S
I-F063	Voices	Vocal/Airy	Vocal	S

S: single mode, D: double mode

#	Name	Category	Sub Category	OSC Mode
I-F064	Rock Guitar	Guitar/Plucked	E.Guitar	D
I-F065	WindBells	SFX	Synthetic	S
I-F066	SynthBass3	Bass/Synth Bass	Synth Bass	S
I-F067	Organ 1	Organ	E.Organ	S
I-F068	Block	Short Decay/Hit	Short Decay	S
I-F069	FingerSnap	Short Decay/Hit	Short Decay	S
I-F070	MagicOrgan	MotionSynth	Motion	S
I-F071	E.Piano 2	Keyboard	Synth E.Piano	S
I-F072	Brass 2	Brass	Ensemble	S
I-F073	Fv Wave	Vocal/Airy	Vocal	S
I-F074	PickGuitar	Guitar/Plucked	E.Guitar	D
I-F075	Digi-Bells	Bell/Mallet	Bell	S
I-F076	AnalogBass	Bass/Synth Bass	Synth Bass	S
I-F077	Ping Wave	Slow Synth	Dark	D
I-F078	Vibe Hit	Short Decay/Hit	Short Decay	S
I-F079	Pluck	Short Decay/Hit	Hit	S
I-F080	Good & Bad	MotionSynth	Motion	D
I-F081	Digital 2	Keyboard	Synth E.Piano	S
I-F082	Mute Trp.	Brass	Solo	S
I-F083	Stratos	MotionSynth	Motion	D
I-F084	Sitar 2	Guitar/Plucked	Plucked	S
I-F085	Flexatone	SFX	Synthetic	S
I-F086	Digital 4	MotionSynth	Motion	S
I-F087	Soft Horns	FastSynth	Short Release	S
I-F088	HellsBells	SFX	Synthetic	D
I-F089	Drop	Short Decay/Hit	Short Decay	S
I-F090	Zephyr	MotionSynth	Motion	D
I-F091	E.Piano 3	Keyboard	Synth E.Piano	S
I-F092	Synthbrass	FastSynth	Short Release	D
I-F093	Digital 5	Slow Synth	Bright	D
I-F094	E.Guitar1	Guitar/Plucked	E.Guitar	S
I-F095	Rhythm	SFX	Synthetic	S
I-F096	Mono Synth	LeadSynth	Hard	S
I-F097	Hold.....	MotionSynth	Motion	D
I-F098	Wait.....	MotionSynth	Motion	D
I-F099	Surprise!!	MotionSynth	Motion	D

S: single mode, D: double mode