

G1 / G1 Air System Firmware Update v1.0.7

June 20, 2018

■ v1.0.7

Fixed a bug related to recording the damper pedal.
Sound select behavior has been improved.

■ Operating requirements

[Windows] Windows7 (32bit/64bit), Windows8.1 (32bit/64bit), Windows10 (32bit/64bit)

[Mac] OS X 10.10, 10.11, 10.12, 10.13

■ USB storage mode

When the G1/G1 Air is in USB storage mode, data can be transferred between its internal memory and an external computer.


1. Connect the G1/G1 Air to the computer using a USB cable.
2. While holding down the METRONOME and Record buttons, press the power button to turn on the G1/G1 Air.
The Play/Pause button lights up, and “USb” appears in the display.




※If the G1/G1 Air is turned off or the USB cable is disconnected while data is being transferred in USB storage mode, G1/G1 Air data or the connected computer may be damaged.

3. Open My Computer, and Click on The drive name “KORG SYSTEM” will appear on your computer.
4. Drag and drop “G1APP.BIN” onto KORG SYSTEM to update files.

[Windows]



[Mac]




5. When you have completed the data transfer, remove the USB drive from the computer desktop.

6. To exit USB storage mode, press the lit Play / Pause button to turn off the G1/G1 Air.

■ System Firmware Version Check

1. While holding down the FUNCTION and G.PIANO buttons, press the power button to turn on the G1/G1 Air.
"107" appears in the display.



2. Press the power button to turn off the G1/G1 Air.