

XE20 Ver 1.4 Release Information

Changes in Ver 1.4

- Adjusted the power-off sequence.

What you will need

- A USB flash drive supported by the XE20 (Needs to have more than 512 MB of free space).
- A computer with a USB port.
- An AC adapter (model KA420).

Checking the software version


- Hold down the SHIFT button and press the power button.
- When your XE20 starts up, the display will show the software version.

Note: If the displayed version number is higher than the update version number, there is no need to update.

- Long press the power button. Your XE20 will now turn off.

Updating the software

- Prepare a USB flash drive that has been formatted by your XE20.
- Insert the USB flash drive into your computer.
- Extract XE20_xxxx.zip.
- Copy "XE20_UPDATE.BIN" from the extracted folder to the root of the USB flash drive.
- Insert the USB flash drive containing the new System file into your XE20, and turn the power on.
- Hold down the SHIFT button and press the MEDIA button. Select "[System Update]" menu using the Cursor [→] button.




- Press the WRITE button. "Cancel [<]" message will be displayed. Select "Yes [WRITE]" using the dial. Press the WRITE button. After a few moments, the new system version number will be displayed.




Note: The displayed version number depends on the update system file.

- Press the WRITE button. A confirmation message will be displayed.
Select " "Yes" " using the dial. Press the WRITE button to begin the update operation.



- ⚠ Depending on the USB flash drive used, it may take several minutes or more.
- ⚠ Do not turn off your XE20 while the update is in progress.

- When the update is completed, the following message will be displayed.



- Long press the power button. Your XE20 will turn off. The system has been successfully updated.