

MANUEL D’UTILISATION

Introduction

Nous vous remercions d’avoir opté pour la **carte d’extension Korg EXB-PCM09 PCM**. Afin d’en profiter sans problème durant de longues années, veuillez lire attentivement le présent manuel et toujours veiller à utiliser la carte correctement.

La carte **EXB-PCM09** contient 128 programmes qui couvrent toute une série de sons de guitare bass, de guitare lead et de pads, des sons désaccordés et des sons de batterie indispensables pour la musique domestique/trance. Elle contient aussi 128 combinaisons (à partir de motifs musicaux) qui utilisent ces programmes et les 16 motifs d’arpège. Elle offre aussi 181 motifs/RPPR (trois morceaux) qui peuvent être utilisés immédiatement dans vos propres morceaux.

Contenu du colis

Carte PCM (EXB-PCM09: 16 Mo) 1
Disquette (EXBPCM-09FD) 1
Manuel d’utilisation 1

Données comprises

Carte PCM (EXB-PCM09: 16 Mo)

La carte **PCM (EXB-PCM09: 16 Mo)** contient 78 multi-échantillons et 240 échantillons de batterie idéaux pour la musique domestique/trance.

Multisample (78): Detune: 36, Bass/Lead: 22, Simple Wave: 9, Sync: 5, Voice Set: 4, SE: 2

Drumsample (240): BD, SD, HH, Perc, Voice (1 shot)

Disquette (EXBPCM-09FD)

La disquette fournie (**EXBPCM-09FD**) contient 128 programmes, 128 combinaisons, 12 ensembles de batterie, 16 motifs d’arpège et 181 motifs/RPPR (trois morceaux) qui utilisent les multi-échantillons et les échantillons de batterie de la carte PCM (EXB-PCM09: 16 Mo).

C_BANK.PCG: Programs: 128 (C)
Combinations: 128 (C)
Drum Kits: 12 (C)
Arpeggio Pattern: 16 (C)

C_BANK.SNG: Song: 3 (Pattern 181)

D_BANK.PCG: Programs: 128 (D)
Combinations: 128 (D)
Drum Kits: 12 (D)

D_BANK.SNG: Arpeggio Pattern: 16 (D)
Song: 3 (Pattern 181)

* Les contenus de C_BANK.PCG et D_BANK.PCG sont identiques et les contenus de C_BANK.SNG et D_BANK.SNG sont identiques.

Mise en place de la carte EXB-PCM09 et chargement des données

Pour plus de détails concernant l’installation de la carte PCM (EXB-PCM09: 16 Mo) et sur le chargement des données, consulter le manuel d’utilisation de l’instrument dans lequel vous comptez installer la carte.

Voici un aperçu de la méthode à suivre.

1. Utiliser "Save All" ("Enregistrer tout" ou une commande équivalente) pour enregistrer toutes les données importantes de la mémoire de l’instrument sur un dispositif de sauvegarde.

▲ Sauvegardez toutes données importantes sur votre propre disque ou sur un autre support. Lorsque vous chargez les

fichiers fournis avec ce produit, toutes les données qui se trouvaient à la destination de la sauvegarde sont effacées.

2. Mettre l’appareil dans lequel vous installez la carte hors tension, débrancher le câble d’alimentation puis installer la carte EXB-PCM (EXB-PCM09: 16 Mo). Après la mise en place de la carte, rebrancher le câble d’alimentation puis remettre l’appareil sous tension. Vérifier si la carte est installée correctement.

3. Après avoir vérifié si la carte est bien installée, charger le fichier PRELOAD.PCG de la disquette fournie avec l’instrument dans lequel vous avez installé la carte.

Les combinaisons et les programmes de la carte EXB-PCM09 utilisent les données suivantes du fichier PRELOAD.PCG.

Program: Bank A and Bank B
Drum Kit: 00-15 (A/B)
Arpeggio Pattern: 000-199 (A/B)

* Sur certains instruments, les banques ci-dessus s’affichent sous forme de I-A, I-B et I-A/B. Néanmoins, les motifs d’arpège ne seront pas chargés ou remplacés sur les instruments qui ne sont pas dotés d’un arpégiateur.

Pour le détail sur la sauvegarde des divers types de données, reportez-vous aux pages suivantes.

TRITON STUDIO: ⇨ BG p.63, 65
TRITON/TRITON pro/TRITON proX: ⇨ BG p.42, 92
TRITON-Rack: ⇨ BG p.42, 82
KARMA: ⇨ BG p.43, 94 (Octobre 02)

4. Charger le fichier C_BANK.PCG ou le fichier D_BANK.PCG de la disquette (EXBPCM-09FD).

Si vous voulez importer le fichier SNG en même temps, cochez soit "Load C_BANK.SNG too" soit "Load D_BANK.SNG too" et appuyez sur [OK]. Les combinaisons de C-Bank ou D-Bank, les données des programmes, des ensembles de batterie, de motifs d’arpège et des morceaux seront chargées.

* Comme C-BANK.PCG et D_BANK.PCG de la carte EXB-PCM09 ne contiennent pas de combinaisons de banques A et B, de programmes, d’ensembles de batterie 00-15 (A/B) et de motifs d’arpège 000-199 (A/B) ni de données globales, ces données ne seront pas chargées.

▲ Les données des fichiers C_BANK.PCG et D_BANK.PCG sont en format TRITON/TRITONpro/TRITONproX. Les réglages particuliers à d’autres modèles ne sont pas compris.

* Comme les données de morceaux sont perdues lorsque l’appareil est éteint, il faut les recharger à la prochaine mise sous tension.

Si vous avez le moindre problème, n’hésitez pas à contacter votre distributeur Korg.

<p>REMARQUE IMPORTANTE POUR LES CLIENTS</p> <p>Ce produit a été fabriqué suivant des spécifications sévères et des besoins en tension applicables dans le pays où ce produit doit être utilisé. Si vous avez acheté ce produit via l’Internet, par vente par correspondance ou/et vente par téléphone, vous devez vérifier que ce produit est bien utilisable dans le pays où vous résidez. ATTENTION: L’utilisation de ce produit dans un pays autre que celui pour lequel il a été conçu peut être dangereuse et annulera la garantie du fabricant ou du distributeur. Conservez bien votre récépissé qui est la preuve de votre achat. Faute de quoi votre produit ne risque de ne plus être couvert par la garantie du fabricant ou du distributeur.</p>

<p>PCMBORD (EXB-PCM09: 16 Mbyte)</p> <p>PCM board (EXB-PCM09: 16 Mbyte) 1 Floppy disk (EXBPCM-09FD) 1 Owner’s manual 1</p>

2. Schalten Sie das für die Installation vorgesehene Instrument aus, ziehen Sie das Netzkabel aus der Steckdose, und setzen Sie dann die Erweiterungskarte EXB-PCM (EXB-PCM09: 16 Mbyte) ein. Nach Einbau der Karte schließen Sie das Netzkabel wieder an und schalten das Gerät ein. Überprüfen Sie, ob die Karte richtig eingesetzt wurde.

3. Nachdem Sie sich vergewissert haben, dass die Karte richtig installiert ist, laden Sie die Datei PRELOAD.PCG von der Diskette o. ä., die mit dem betreffenden Instrument geliefert wurde.

Die Kombinationen und Programme von EXB-PCM09 verwenden die folgenden Daten aus der Datei PRELOAD.PCG.

Program: Bank A and Bank B
Drum Kit: 00-15 (A/B)
Arpeggio Pattern: 000-199 (A/B)

* Bei einigen Instrumenten werden die obigen Bänke als I-A, I-B und I-A/B angezeigt. Bei Instrumenten, die keinen Arpeggiator besitzen, werden die Arpeggio-Pattern nicht geladen (bzw. nicht überschrieben).

Einzelheiten zum Laden verschiedener Datentypen siehe folgende Seiten.

TRITON STUDIO: ⇨ BG p.63, 65
TRITON/TRITON pro/TRITON proX: ⇨ BG p.42, 92
TRITON-Rack: ⇨ BG p.42, 82
KARMA: ⇨ BG p.43, 94 (Oktober / 02)

4. Laden Sie die Datei C_BANK.PCG oder D_BANK.PCG von der Diskette (EXBPCM-09FD).

Wenn Sie die Datei SNG gleichzeitig laden wollen, markieren Sie entweder "Load C_BANK.SNG too" oder "Load D_BANK.SNG too", und drücken dann OK. Die C-Bank- oder D-Bank-Kombinationen, Programme, Drum-Kits, Arpeggio-Patterns und Song-Daten werden geladen.

* Da C_BANK.PCG und D_BANK.PCG der EXB-PCM09 nicht die A- und B-Bank-Kombinationen, Programme, Drum-Kits 00-15 (A/B) und Arpeggio-Patterns 000-199 (A/B) und globale Daten enthalten, werden diese Daten nicht geladen.

▲ Die Werksdateien auf den Disketten C_BANK.PCG und D_BANK.PCG beruhen auf dem TRITON/TRITONpro/TRITONproX-Format. Einstellungen, die spezifisch für andere Modelle sind, sind nicht enthalten.

* Da Song-Daten beim Ausschalten verloren gehen, müssen Sie sie beim nächsten Einschalten neu laden.

Falls etwas unklar ist, wenden Sie sich bitte an Ihren Korg-Händler.

<p>WICHTIGER HINWEIS FÜR KUNDEN</p> <p>Dieses Produkt wurde unter strenger Beachtung von Spezifikationen und Spannungsanforderungen hergestellt, die im Bestimmungsland gelten. Wenn Sie dieses Produkt über das Internet, per Postversand und/oder mit telefonischer Bestellung gekauft haben, müssen Sie bestätigen, dass dieses Produkt für Ihr Wohngebiet ausgelegt ist. WARNING: Verwendung dieses Produkts in einem anderen Land als dem, für das es bestimmt ist, verwendet wird, kann gefährlich sein und die Garantie des Herstellers oder Importeurs hinfällig lassen werden. Bitte bewahren Sie diese Quittung als Kaufbeleg auf, da andernfalls das Produkt von der Garantie des Herstellers oder Importeurs ausgeschlossen werden kann.</p>
--

<p>お願ひ</p> <p>1.保証書に販売年月日等の記入がない場合は無効となります。記入できないときは、お買い上げ年月日を証明できる領収書等と一緒に保管してください。 2.保証書は再発行致しませんので、紛失しないように大切に保管してください。</p>
--

<p>コルグ EXB-PCM09</p> <p>本保証書は上記の保証規定により無料修理を行うことをお約束するものです。お買い上げ日から満1年の間に万一故障が発生した場合は、製品と共に本保証書を必ずご持参の上、修理を依頼してください。</p>
<p>お買い上げ日</p> <p>販売店名</p>

アフターサービス

アフターサービスについてのご質問、ご相談は、お買い上げの販売店、最寄りのコルグ営業所、またはサービス・センターへお問い合わせください。商品のお取り扱いに関するご質問、ご相談は、お客様相談窓口へお問い合わせください。

<p>お客様相談窓口 TEL 03(3799)9086</p>
<p>サービス・センター: 〒143-0001 東京都中央区東區5-4-1 明正大井5号営業所 コルグ物流センター内 TEL 03(3799)9085 名古屋営業所: 〒466-0825 名古屋昭和区八事本町100-51 TEL 052(832)1419 大阪営業所: 〒531-0072 大阪市北区豊崎3-2-1淀川5番館7F TEL 06(6374)0691 福岡営業所: 〒810-0012 福岡市中央区白金1-3-25第2池田ビルF TEL 092(531)0166</p>

KORG EXB-PCM09 PCM EXPANSION BOARD CARTE D'EXTENSION PCM TRANCE ATTACK

KORG KORG INC.

15-12, Shimotakaido 1-chome, Suginami-ku, Tokyo, Japan

© 2002 KORG INC.

<p> E F G J 1</p>
<p>1410 CTH <i>Printed in Japan</i></p>

OWNER'S MANUAL

<p>This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Complies with Canadian ICES-003 Class B. Conforme au Reglement Canadien NMB-003 classe B.</p>
--

Introduction

Thank you for purchasing the **Korg EXB-PCM09 PCM expansion board**. To ensure years of trouble-free enjoyment, please read this owner's manual carefully and use the product correctly.

The **EXB-PCM09** contains 128 programs that cover a broad selection of synth bass, lead, pads, detuned sounds and drum sounds that are indispensable for house/trance music. It also contains 128 combinations (most of them based on rhythmic patterns) that use these programs and the 16 arpeggio patterns. Also included are 181 patterns/RPPR (three songs) that you can use immediately in your own songs.

Contents of the package

PCM board (EXB-PCM09: 16 Mbyte) 1
Floppy disk (EXBPCM-09FD) 1
Owner’s manual 1

Included data

PCM board (EXB-PCM09: 16 Mbyte)

The PCM board (**EXB-PCM09: 16 Mbyte**) contains 78 multisamples and 240 drum samples ideal for house/trance music.

Multisample (78): Detune: 36, Bass/Lead: 22, Simple Wave: 9, Sync: 5, Voice Set: 4, SE: 2

Drumsample (240): BD, SD, HH, Perc, Voice (1 shot)

Floppy disk (EXBPCM-09FD)

The included floppy disk (**EXBPCM-09FD**) contains 128 programs, 128 combinations, 12 drum kits, 16 arpeggio patterns, and 181 patterns/RPPR (three songs) that use the multisamples and drum samples of the PCM board (EXB-PCM09: 16 Mbyte).

C_BANK.PCG: Programs: 128 (C)
Combinations: 128 (C)
Drum Kits: 12 (C)
Arpeggio Pattern: 16 (C)

C_BANK.SNG: Song: 3 (Pattern 181)

D_BANK.PCG: Programs: 128 (D)
Combinations: 128 (D)
Drum Kits: 12 (D)

D_BANK.SNG: Arpeggio Pattern: 16 (D)
Song: 3 (Pattern 181)

* The contents of C_BANK.PCG and D_BANK.PCG are identical, and the contents of C_BANK.SNG and D_BANK.SNG are identical.

Installing the EXB-PCM09 and loading the data

For details on how to install the PCM board (EXB-PCM09: 16 Mbyte) and load the data, refer to the owner’s manual of the instrument into which you are installing the board. Here is an overview of the process.

取扱説明書

はじめに

このたびは、コルグ**PCM**エクスパンジョン・ボード**EXB-PCM09**をお買い上げいただきまして誠にありがとうございます。本製品を末長くご愛用いただくためにも、この取扱説明書や、取り付ける機器の取扱説明書をよくお読みになって正しい方法でご使用ください。

EXB-PCM09は、ハウス/トランス・ミュージックに欠かせないシンセ・ベース、リード、パッド、デチューン・サウンドやドラム・サウンドなど128プログラムと、これらのプログラムと16種のアルペジオ・パターンを駆使したリズムックなパターンを中心とした128コンビネーションを収録しています。その他、曲づくりですぐに使える181パターン/RPPR(3ソング分)を収録しています。

<p>パッケージ内容</p> <p>PCMボード (EXB-PCM09: 16Mbyte) 1 フロッピー・ディスク (EXBPCM-09FD) 1 取扱説明書 1</p>

収録データ

PCMボード (EXB-PCM09: 16Mbyte)

PCMボード (**EXB-PCM09: 16Mbyte**)は、ハウス/トランス・ミュージックに適した78マルチサンプル、240ドラムサンプルを収録しています。

Multisample (78): Detune: 36, Bass/Lead: 22, Simple Wave: 9, Sync: 5, Voice Set: 4, SE: 2

Drumsample (240): BD, SD, HH, Perc, Voice (1 shot)

フロッピー・ディスク (EXBPCM-09FD)

付属フロッピー・ディスク(**EXBPCM-09FD**)は、PCMボード(EXB-PCM09: 16Mbyte)のマルチサンプル、ドラムサンプルを使用した128プログラムと、128コンビネーション、12ドラムキットと、16アルペジオ・パターン、181パターン/RPPR(3ソング分)を収録しています。

C_BANK.PCG: Programs: 128 (C)
Combinations: 128 (C)
Drum Kits: 12 (C)
Arpeggio Pattern: 16 (C)

C_BANK.SNG: Song: 3 (Pattern 181)

D_BANK.PCG: Programs: 128 (D)
Combinations: 128 (D)
Drum Kits: 12 (D)

D_BANK.SNG: Arpeggio Pattern: 16 (D)
Song: 3 (Pattern 181)

* C_BANK.PCGとD_BANK.PCG、C_BANK.SNGとD_BANK.SNGの内容は同じものです。

OWNER’S MANUAL MANUEL D’UTILISATION BEDIENUNGSANLEITUNG

取扱説明書

KORG EXB-PCM09 PCM EXPANSION BOARD CARTE D'EXTENSION PCM TRANCE ATTACK

KORG KORG INC.

15-12, Shimotakaido 1-chome, Suginami-ku, Tokyo, Japan

© 2002 KORG INC.

<p> E F G J 1</p>
<p>1410 CTH <i>Printed in Japan</i></p>

OWNER'S MANUAL

1. Use "Save All" (or an equivalent command) to save any important data from the memory of the instrument to storage media.

▲ You should back up important data onto your own disk or other storage medium. When you load the files included with this product, any data that was previously in the loading-destination will be overwritten.

2. Turn off the power of the instrument into which you are installing the board, disconnect the power cable, and then install the EXB-PCM board (EXB-PCM09: 16 Mbyte). After installing the board, re-connect the power cable and turn on the power. Verify that the board was installed correctly.

3. After you have verified that the board is correctly installed, load the PRELOAD.PCG file from such as floppy disk which was provided with the instrument in which you installed the board.

The combinations and programs of the EXB-PCM09 use the following data from the PRELOAD.PCG file.

Program: Bank A and Bank B
Drum Kit: 00-15 (A/B)
Arpeggio Pattern: 000-199 (A/B)

* On some instruments, the above banks will be displayed as I-A, I-B, and I-A/B. The arpeggio patterns will not be loaded or overwritten on instruments that do not contain an arpeggiator.

For details on loading various types of data, refer to the following pages.

TRITON STUDIO: ⇨ BG p.63, 65
TRITON/TRITON pro/TRITON proX: ⇨ BG p.42, 92
TRITON-Rack: ⇨ BG p.42, 82
KARMA: ⇨ BG p.43, 94 (October / 02)

4. Load the C_BANK.PCG file or D_BANK.PCG file from the floppy disk (EXBPCM-09FD).

If you want to load the SNG file at the same time, check either "Load C_BANK.SNG too" or "Load D_BANK.SNG too", and then press OK. The C-bank or D-bank combinations, programs, drum kits, arpeggio patterns, and song data will be loaded.

* Since C_BANK.PCG and D_BANK.PCG of the EXB-PCM09 do not contain A- and B-bank combinations, programs, drum kits 00-15 (A/B), and arpeggio patterns 000-199 (A/B), and global data, this data will not be loaded.

▲ The C_BANK.PCG and D_BANK.PCG data is in the TRITON/TRITONpro/TRITONproX format. Settings that are specific to other models are not included.

* Since song data is lost when you turn off the power, you will need to reload it the next time you turn on the power.

If you have any questions, please contact your Korg distributor.

<p>IMPORTANT NOTICE TO CONSUMERS</p> <p>This product has been manufactured according to strict specifications and voltage requirements that are applicable in the country in which it is intended that this product should be used. If you have purchased this product via the internet, through mail order, and/or via a telephone sale, you must verify that this product is intended to be used in the country in which you reside. WARNING: Use of this product in any country other than that for which it is intended could be dangerous and could invalidate the manufacturer’s or distributor’s warranty. Please also retain your receipt as proof of purchase otherwise your product may be disqualified from the manufacturer’s or distributor’s warranty.</p>
--

取扱説明書

このたびは、コルグ**PCM**エクスパンジョン・ボード**EXB-PCM09**をお買い上げいただきまして誠にありがとうございます。本製品を末長くご愛用いただくためにも、この取扱説明書や、取り付ける機器の取扱説明書をよくお読みになって正しい方法でご使用ください。

EXB-PCM09は、ハウス/トランス・ミュージックに欠かせないシンセ・ベース、リード、パッド、デチューン・サウンドやドラム・サウンドなど128プログラムと、これらのプログラムと16種のアルペジオ・パターンを駆使したリズムックなパターンを中心とした128コンビネーションを収録しています。その他、曲づくりですぐに使える181パターン/RPPR(3ソング分)を収録しています。

パッケージ内容

PCMボード (EXB-PCM09: 16Mbyte) 1
フロッピー・ディスク (EXBPCM-09FD) 1
取扱説明書 1

収録データ

PCMボード (**EXB-PCM09: 16Mbyte**)は、ハウス/トランス・ミュージックに適した78マルチサンプル、240ドラムサンプルを収録しています。

Multisample (78): Detune: 36, Bass/Lead: 22, Simple Wave: 9, Sync: 5, Voice Set: 4, SE: 2

Drumsample (240): BD, SD, HH, Perc, Voice (1 shot)

フロッピー・ディスク (EXBPCM-09FD)

付属フロッピー・ディスク(**EXBPCM-09FD**)は、PCMボード(EXB-PCM09: 16Mbyte)のマルチサンプル、ドラムサンプルを使用した128プログラムと、128コンビネーション、12ドラムキットと、16アルペジオ・パターン、181パターン/RPPR(3ソング分)を収録しています。

C_BANK.PCG: Programs: 128 (C)
Combinations: 128 (C)
Drum Kits: 12 (C)
Arpeggio Pattern: 16 (C)

C_BANK.SNG: Song: 3 (Pattern 181)

D_BANK.PCG: Programs: 128 (D)
Combinations: 128 (D)
Drum Kits: 12 (D)

D_BANK.SNG: Arpeggio Pattern: 16 (D)
Song: 3 (Pattern 181)

* C_BANK.PCGとD_BANK.PCG、C_BANK.SNGとD_BANK.SNGの内容は同じものです。

ご不明な点はコルグお客様相談窓口へお問い合わせください。

保証規定(必ずお読みください)

本保証書は、保証期間中に本製品を保証するもので、付属品類は保証の対象になりません。保証期間内に本製品が故障した場合は、保証規定によって無償修理いたします。

1.本保証書の有効期間はお買い上げ日より1年です。
2.次の修理等は保証期間内であっても有料修理となります。
・消耗部品(電池など)の交換。
・お取扱い方法が不適当のために生じた故障。
・天災(火災、浸水等)によつて生じた故障。
・故障の原因が本製品以外の他の機器にある場合。
・不当な改造、調整、部品交換などにより生じた故障または損傷。
・保証書にお買い上げ日、販売店名が未記入の場合、または字句が書き替えられている場合。
・本保証書の提示がない場合。

尚、当社が修理した部分が再度故障した場合は、保証期間外であっても、修理した日より3ヶ月以内に限り無償修理いたします。

3.本保証書は日本国内においてのみ有効です。
This warranty is valid only in Japan.

4.お客様が保証期間中に移転された場合でも、保証は引き続きお使いいただけます。最寄りのコルグ営業所、またはサービス・センターまでお問い合わせください。
5.修理、運送費用が製品の価格より高くなることもありますが、あらかじめ最寄りのコルグ営業所、またはサービス・センターへご相談ください。運送にかかる往復の費用はお客様の負担とさせていただきます。

本製品の故障、または使用上生じたお客様の直接、間接の損傷につきましては、弊社はいっさいの責任を負いかねますのでご了承ください。

本保証書は、保証規定により無料修理をお約束するためのもので、これよりお客様の法律上の権利を制限するものではありません。

Combinations

C/D #	Name	Category	C/D #	Name	Category	C/D #	Name	Category
000	Trance Anthem	Rhythmic Pattern	040	Deep Voz Pad	Pads	080	Intro...	Rhythmic Pattern
001	Pure Energy	Rhythmic Pattern	041	Traxendental	Rhythmic Pattern	081	Swinging Party	Rhythmic Pattern
002	Hard House	Rhythmic Pattern	042	Rave Killer	Rhythmic Pattern	082	Hard at It	Rhythmic Pattern
003	Free Weave	Rhythmic Pattern	043	Power Beat	Rhythmic Pattern	083	Nasal Passage	Rhythmic Pattern
004	Goa In For It	Rhythmic Pattern	044	Can't Remember	Rhythmic Pattern	084	Sweet Asway	MotionSynth
005	K A M P U S	Rhythmic Pattern	045	VocalPad/Land	Pads	085	Ae Ureally U?	Rhythmic Pattern
006	Killer Tune	Rhythmic Pattern	046	Beyond the World	Rhythmic Pattern	086	Cloud Travel	Rhythmic Pattern
007	Sea Wave	Rhythmic Pattern	047	2 Finger Magik	Rhythmic Pattern	087	Eternity	Rhythmic Pattern
008	Infinity Pad	Synth	048	Majority Rules	Ds/Hits	088	Out On The Floor	Rhythmic Pattern
009	Goanna...	Rhythmic Pattern	049	ResonanceParty	Rhythmic Pattern	089	Chill w/ my Piano	Keyboard
010	Know Trance	Rhythmic Pattern	050	SW17 Breakdown	Rhythmic Pattern	090	ChordBlocker	Rhythmic Pattern
011	Hard Groove	Rhythmic Pattern	051	SquaredOrCubed?	Rhythmic Pattern	091	Syncro Sonic	Rhythmic Pattern
012	PursuitOfJustice	Rhythmic Pattern	052	Death Groove	Rhythmic Pattern	092	Flanged Pad	MotionSynth
013	MessTrance Pad	Pads	053	Xperiment YZ52	Rhythmic Pattern	093	UltraAnoString	MotionSynth
014	Electrified	Rhythmic Pattern	054	Lookin 4 Trouble	Rhythmic Pattern	094	Vox N-Jams	Complex & SE
015	U no U Want It	Rhythmic Pattern	055	Voco Loco	Rhythmic Pattern	095	Hard House Bells	Rhythmic Pattern
016	DaDaDa	Rhythmic Pattern	056	Nights Of Fire	Rhythmic Pattern	096	DrVpuffyTrance	Rhythmic Pattern
017	Know Trance	Rhythmic Pattern	057	Tekno Overture	Rhythmic Pattern	097	ClonBlocker	Rhythmic Pattern
018	SeriousBleeper	Rhythmic Pattern	058	Pop Pizza	Rhythmic Pattern	098	Detune Massive	Synth
019	Goa Abduction	Rhythmic Pattern	059	Crowd Pleaser	Rhythmic Pattern	099	National Pulse	Rhythmic Pattern
020	Feel Wide Bass	Complex & SE	060	Amazing Strings	Strings	100	ATGater(SWBUILD)	Rhythmic Pattern
021	DEEP in da House	Rhythmic Pattern	061	AssimilatedArps	MotionSynth	101	Dawn Dancer	Rhythmic Pattern
022	Cell Phone City	Rhythmic Pattern	062	Female Xpansions	Complex & SE	102	Heart To Heart	Rhythmic Pattern
023	Surrender Now	Rhythmic Pattern	063	Dach Groove	Ds/Hits	103	Misty Morning	Rhythmic Pattern
024	Awake All Night	LeadSynth	064	TheMissingBleep	Rhythmic Pattern	104	Vocalist	MotionSynth
025	Sunrise @ IBIZA	MotionSynth	065	Beauty/Beast	Rhythmic Pattern	105	Green Springs	Synth
026	OAB Techno	Rhythmic Pattern	066	Trance Blade	Synth	106	Quadrangle	Rhythmic Pattern
027	Hard Hitting	Ds/Hits	067	Cyber Dance	Rhythmic Pattern	107	DreamState...	MotionSynth
028	Large one	MotionSynth	068	5th Movement	Rhythmic Pattern	108	TimeOut...	MotionSynth
029	Counterpoint Arp	MotionSynth	069	Blood Pressure	Rhythmic Pattern	109	Gated Paddling	MotionSynth
030	Male Xpansions	Complex & SE	070	Love Me Tonight	Rhythmic Pattern	110	Crop Circling	Rhythmic Pattern
031	Kasidy KAO CS Kit	Rhythmic Pattern	071	Edition ARP	Rhythmic Pattern	111	Did U See God?	Rhythmic Pattern
032	Night Flight	Rhythmic Pattern	072	Edition ARP	Synth	112	Mad at the World	Rhythmic Pattern
033	Goose Wab Bass	Rhythmic Pattern	073	Pickled	Rhythmic Pattern	113	LC Nagger	Rhythmic Pattern
034	Hard Floor	Rhythmic Pattern	074	Hard Project	Rhythmic Pattern	114	Hard Bleeper	Rhythmic Pattern
035	The Horizon	Rhythmic Pattern	075	Heavy Groove	Rhythmic Pattern	115	EnsembSynPizz	Synth
036	TranceBuildSW1/2	Rhythmic Pattern	076	SlowGroover	Rhythmic Pattern	116	High Synx Lead	Synth
037	Komplicate	Rhythmic Pattern	077	PSG Gated Pad	MotionSynth	117	Organ Bass	Rhythmic Pattern
038	Jumpin' Pumpin'	Rhythmic Pattern	078	OOD Techno	Rhythmic Pattern	118	Euphoric Bass	Rhythmic Pattern
039	Planet of Love	Rhythmic Pattern	079	U DO Tekno ?	Rhythmic Pattern	119	Confirmation	Rhythmic Pattern

Programs

C/D #	Name	Category	C/D #	Name	Category	C/D #	Name	Category
000	MassiveKillerPad	FastSynth	040	BaBaBass	Bass	080	ISaw&ISquared	MotionSynth
001	Nu Goa Synth	FastSynth	041	Gravwrk Bass	Bass	081	Voxic	Vocal/Airy
002	Anthem Tool	FastSynth	042	Unison Bass	Bass	082	Breath of God	Vocal/Airy
003	Nasal Bozz	Hit/Arppg	043	Avrel Tea Bee	Bass	083	Trance Stab	FastSynth
004	Sub Arp	Hit/Arppg	044	LFO Trance Lead	LeadSynth	084	Massive Fad	FastSynth
005	Pulse Bass	Bass	045	Psycho Stab	LeadSynth	085	BlackBoard	FastSynth
006	Saw Bass	Bass	046	Wide Detune Lead	LeadSynth	086	Detuned SynS	FastSynth
007	Infected Bass	Bass	047	Shrap Detox	LeadSynth	087	Big Dancer	FastSynth
008	Antic Bass	Bass	048	F Free Btate PWM	LeadSynth	088	Killer DetunSvn	FastSynth
009	Pretty Pad	SlowSynth	049	HARD LIner (LeadSynth	089	Fat Fogger	FastSynth
010	Arp Bass 2	MotionSynth	050	ArpBtAT	LeadSynth	090	Industrial Stab	FastSynth
011	LightOffTheSource	MotionSynth	051	Big Fog Horn	LeadSynth	091	Xtreme Edge	FastSynth
012	Bract Oct Synth	FastSynth	052	Toxic Lead	LeadSynth	092	EuroSynth	FastSynth
013	DetuneTranceLead	LeadSynth	053	Morpher Lead	LeadSynth	093	Dreamy Punk	FastSynth
014	Rebel Lead	LeadSynth	054	MS-2000 Sync 1	LeadSynth	094	Pulse Width Mod	FastSynth
015	Saw Lead/Bass	LeadSynth	055	MS-2000 Sync 2	LeadSynth	095	Dvna-Saw-Rus-Res	FastSynth
016	Pumpin' Kit	Drums	056	HardBody Lead	LeadSynth	096	Pure Pulse	FastSynth
017	She's a GOA!	Drums	057	Pulse Paddling	SlowSynth	097	Phone Boy	FastSynth
018	Male Voice SW1	SE	058	Thick Pad	SlowSynth	098	Minority	FastSynth
019	FemaleVoice3 SW1	SE	059	KillerPadSW1R1bb	SlowSynth	099	Puncher	FastSynth
020	Strato Grand	Keyboard	060	Introduction	MotionSynth	100	RiDude Pancher	FastSynth
021	Transonic Grand	Keyboard	061	Euphorism	MotionSynth	101	Widow Maker	FastSynth
022	Plus Puls	Bass	062	Trance Scream	MotionSynth	102	Trance Hit	Hit/Arppg
023	Attack Sub Bass	Bass	063	European Stab	MotionSynth	103	Mega Pulse HIt	Hit/Arppg
024	Breaker Bass	Bass	064	StAbInTheDark	MotionSynth	104	Wake Up Now!	Hit/Arppg
025	Square Face Bass	Bass	065	Cookin Oil	MotionSynth	105	Madal Hit	Hit/Arppg
026	PWM Lead/Bass	Bass	066	Dream Catcher	MotionSynth	106	7th House Hit	Hit/Arppg
027	Deep nD Bass	Bass	067	Red Rain	MotionSynth	107	Svnc Slider	Hit/Arppg
028	Mondo Synx Bass	Bass	068	Bombers Pad	MotionSynth	108	ArppHEAD	Hit/Arppg
029	Snappy Bass/Lead	Bass	069	Trance In Motion	MotionSynth	109	SynpH TRANCE	Hit/Arppg
030	Did U See God?	Bass	070	Strom Chaser	MotionSynth	110	ArppHEAD	Hit/Arppg
031	Deep Organ Bass	Bass	071	Sonic Throber	MotionSynth	111	Dub Panner	Hit/Arppg
032	Bass-Depot	Bass	072	MonolithMotion	MotionSynth	112	SimmerReso	Hit/Arppg
033	Mondo Saw Bass	Bass	073	Wave Hunter	MotionSynth	113	TEK No Kit 1	Drums
034	Monopoly Bass	Bass	074	WelcomeToMyWorld	MotionSynth	114	TEK No Kit 2	Drums
035	Reso Stereo Bass	Bass	075	Man Of War	MotionSynth	115	DrumBass(Ma...)	Drums
036	VelobASS	Bass	076	Hard L.F.O.	MotionSynth	116	Hard Kit 1	Drums
037	Tunnel Bass	Bass	077	Robotica	MotionSynth	117	Hard Kit 2	Drums
038	Phone Bass	Bass	078			118		
039	Phone Bass	Bass	079			119		

↑ : single program, ↓ : double program, ⊕ : Drums program

Drum kits

16/32: TekNo Kit 1			17/33: TekNo Kit 2			18/34: Trance Kit 1			19/35: Trance Kit 2			20/36: Hard Kit 1			21/37: Hard Kit 2			22/38: Pumpin' Kit			23/39: PhatBoy Kit			24/40: Nu Trix Kit			25/41: Xtreme Kit			26/42: Grand Slam Kit			27/43: Techno Perc		
Note	Bank	Drumsample #	Note	Bank	Drumsample #	Note	Bank	Drumsample #	Note	Bank	Drumsample #	Note	Bank	Drumsample #	Note	Bank	Drumsample #	Note	Bank	Drumsample #	Note	Bank	Drumsample #	Note	Bank	Drumsample #	Note	Bank	Drumsample #	Note	Bank	Drumsample #	Note	Bank	Drumsample #
C1	EXB9_29	EXB9_29	C1	EXB9_29	EXB9_29	C1	EXB9_129	EXB9_129	C1	EXB9_129	EXB9_129	C1	EXB9_315	EXB9_315	C1	EXB9_315	EXB9_315	C1	EXB9_132	EXB9_132	C1	EXB9_132	EXB9_132	C1	EXB9_132	EXB9_132	C1	EXB9_132	EXB9_132	C1	EXB9_132	EXB9_132			
D1	EXB9_47	EXB9_47	D1	EXB9_47	EXB9_47	D1	EXB9_166	EXB9_166	D1	EXB9_166	EXB9_166	D1	EXB9_339	EXB9_339	D1	EXB9_339	EXB9_339	D1	EXB9_138	EXB9_138	D1	EXB9_138	EXB9_138	D1	EXB9_138	EXB9_138	D1	EXB9_138	EXB9_138	D1	EXB9_138	EXB9_138			
F1	EXB9_167	EXB9_167	F1	EXB9_167	EXB9_167	F1	EXB9_291	EXB9_291	F1	EXB9_291	EXB9_291	F1	EXB9_331	EXB9_331	F1	EXB9_331	EXB9_331	F1	EXB9_141	EXB9_141	F1	EXB9_141	EXB9_141	F1	EXB9_141	EXB9_141	F1	EXB9_141	EXB9_141	F1	EXB9_141	EXB9_141			
F#1	EXB9_168	EXB9_168	F#1	EXB9_168	EXB9_168	F#1	EXB9_289	EXB9_289	F#1	EXB9_289	EXB9_289	F#1	EXB9_337	EXB9_337	F#1	EXB9_337	EXB9_337	F#1	EXB9_142	EXB9_142	F#1	EXB9_142	EXB9_142	F#1	EXB9_142	EXB9_142	F#1	EXB9_142	EXB9_142	F#1	EXB9_142	EXB9_142			
G1	EXB9_168	EXB9_168	G1	EXB9_168	EXB9_168	G1	EXB9_60	EXB9_60	G1	EXB9_60	EXB9_60	G1	EXB9_343	EXB9_343	G1	EXB9_343	EXB9_343	G1	EXB9_143	EXB9_143	G1	EXB9_143	EXB9_143	G1	EXB9_143	EXB9_143	G1	EXB9_143	EXB9_143	G1	EXB9_143	EXB9_143			
A1	EXB9_161	EXB9_161	A1	EXB9_161	EXB9_161	A1	EXB9_312	EXB9_312	A1	EXB9_312	EXB9_312	A1	EXB9_350	EXB9_350	A1	EXB9_350	EXB9_350	A1	EXB9_145	EXB9_145	A1	EXB9_145	EXB9_145	A1	EXB9_145	EXB9_145	A1	EXB9_145	EXB9_145	A1	EXB9_145	EXB9_145			
B1	EXB9_162	EXB9_162	B1	EXB9_162	EXB9_162	B1	EXB9_20	EXB9_20	B1	EXB9_20	EXB9_20	B1	EXB9_352	EXB9_352	B1	EXB9_352	EXB9_352	B1	EXB9_146	EXB9_146	B1	EXB9_146	EXB9_146	B1	EXB9_146	EXB9_146	B1	EXB9_146	EXB9_146	B1	EXB9_146	EXB9_146			
C2	EXB9_11	EXB9_11	C2	EXB9_11	EXB9_11	C2	EXB9_38	EXB9_38	C2	EXB9_38	EXB9_38	C2	EXB9_316	EXB9_316	C2	EXB9_316	EXB9_316	C2	EXB9_22	EXB9_22	C2	EXB9_22	EXB9_22	C2	EXB9_22	EXB9_22	C2	EXB9_22	EXB9_22	C2	EXB9_22	EXB9_22			
C#2	EXB9_32	EXB9_32	C#2	EXB9_32	EXB9_32	C#2	EXB9_39	EXB9_39	C#2	EXB9_39	EXB9_39	C#2	EXB9_317	EXB9_317	C#2	EXB9_317	EXB9_317	C#2	EXB9_23	EXB9_23	C#2	EXB9_23	EXB9_23	C#2	EXB9_23	EXB9_23	C#2	EXB9_23	EXB9_23	C#2	EXB9_23	EXB9_23			
D2	EXB9_51	EXB9_51	D2	EXB9_51	EXB9_51	D2	EXB9_15	EXB9_15	D2	EXB9_15	EXB9_15	D2	EXB9_318	EXB9_318	D2	EXB9_318	EXB9_318	D2	EXB9_24	EXB9_24	D2	EXB9_24	EXB9_24	D2	EXB9_24	EXB9_24	D2	EXB9_24	EXB9_24	D2	EXB9_24	EXB9_24			
E2	EXB9_11	EXB9_11	E2	EXB9_11	EXB9_11	E2	EXB9_42	EXB9_42	E2	EXB9_42	EXB9_42	E2	EXB9_319	EXB9_319	E2	EXB9_319	EXB9_319	E2	EXB9_25	EXB9_25	E2	EXB9_25	EXB9_25	E2	EXB9_25	EXB9_25	E2	EXB9_25	EXB9_25	E2	EXB9_25	EXB9_25			
F2	EXB9_51	EXB9_51	F2	EXB9_51	EXB9_51	F2	EXB9_40	EXB9_40	F2	EXB9_40	EXB9_40	F2	EXB9_320	EXB9_320	F2	EXB9_320	EXB9_320	F2	EXB9_26	EXB9_26	F2	EXB9_26	EXB9_26	F2	EXB9_26	EXB9_26	F2	EXB9_26	EXB9_26	F2	EXB9_26	EXB9_26			
G2	EXB9_53	EXB9_53	G2	EXB9_53	EXB9_53	G2	EXB9_44	EXB9_44	G2	EXB9_44	EXB9_44	G2	EXB9_321	EXB9_321	G2	EXB9_321	EXB9_321	G2	EXB9_27	EXB9_27	G2	EXB9_27	EXB9_27	G2	EXB9_27	EXB9_27	G2	EXB9_27	EXB9_27	G2	EXB9_27	EXB9_27			
G#2	EXB9_162	EXB9_162	G#2	EXB9_162	EXB9_162	G#2	EXB9_42	EXB9_42	G#2	EXB9_42	EXB9_42	G#2	EXB9_322	EXB9_322	G#2	EXB9_322	EXB9_322	G#2	EXB9_28	EXB9_28	G#2	EXB9_28	EXB9_28	G#2	EXB9_28	EXB9_28	G#2	EXB9_28	EXB9_28	G#2	EXB9_28	EXB9_28			
A#2	EXB9_168	EXB9_168	A#2	EXB9_168	EXB9_168	A#2	EXB9_55	EXB9_55	A#2	EXB9_55	EXB9_55	A#2	EXB9_323	EXB9_323	A#2	EXB9_323	EXB9_323	A#2	EXB9_29	EXB9_29	A#2	EXB9_29	EXB9_29	A#2	EXB9_29	EXB9_29	A#2	EXB9_29	EXB9_29	A#2	EXB9_29	EXB9_29			
B2	EXB9_3	EXB9_18	B2	EXB9_18	EXB9_18	B2	EXB9_9	EXB9_9	B2	EXB9_9	EXB9_9	B2	EXB9_324	EXB9_324	B2	EXB9_324	EXB9_324	B2	EXB9_30	EXB9_30	B2	EXB9_30	EXB9_30	B2	EXB9_30	EXB9_30	B2	EXB9_30	EXB9_30	B2	EXB9_30	EXB9_30			
C3																																			