

electribe Ver 1.19 Release Information

Changes in Ver 1.19 from Ver 1.18

Bug fix

- Fixed a bug related to “SOFTWARE UPDATE”

What you will need

- Memory card supported by electribe
 - Computer with memory card adapter
 - AC adapter KA350 or six AA batteries
-  **Make sure the batteries are brand new if using alkaline or fully charged if using NiMH batteries.**

Updating the software

- Prepare a memory card that has been formatted by electribe.
- Insert the memory card into your card reader, and connect it to your computer.
- Extract electribe_xxxx.zip.
- Copy "SYSTEM.VSB" into the [System] folder under the [KORG][electribe] folder on the memory card.
- Insert the memory card containing the new system file into your electribe, and turn on the power.
- Select "SOFTWARE UPDATE" from the DATA UTILITY menu.

```
Data Util 25/26  EDIT  [Left] [Right]
DATA UTILITY
press [ Enter ]
```

```
Data Util 10/10  EDIT  [Left] [Right]
SOFTWARE UPDATE
press [ Enter ]
```

- Press Menu/Enter. Current version and new version will appear. Press Menu/Enter button.

```
Data Util  8/10  EDIT  [Left] [Right]
SOFTWARE UPDATE
Now Version : 1.18
Next Version : 1.19
press [ Enter ]
```

- A confirmation message will appear. Press Menu/Enter button to begin the update operation.

```
Data Util 8/10  EDIT  ■■■  
SOFTWARE UPDATE  
Are You Sure ?  
press [ Enter ]
```



Do not turn off electribe while update is in progress.

- electribe will display the following screen when update is complete.

```
Data Util 8/10  EDIT  ■■■  
SOFTWARE UPDATE  
OK. Please Reboot.
```

- Long push the power button. electribe will now turn off. The system has been updated.