[Slim-Line USB Keyboard]

MIDI Implementation Chart

anoKEY			entation Chart	1
Function		Transmitted	Recognized	Remarks
Basic Channel	Default Changed	1 – 16 1 – 16	××	Memorized
Mode	Memorized Messages Altered	× ○ ******	××	*1
Note Number:	True Voice	0 – 127 ******	××	
Velocity	Note On Note Off	○ 1 – 127 ○ 64	××	
Aftertouch	Polyphonic (Key) Monophonic (Channel)	××	××	
Pitch Bend		0	×	[PITCH] button
Control Change	0 – 127	0	×	Keyboard (CC Mode), [MOD] button
Program Change	Variable Range	× ******	× ******	
System Exclusive		0	0	*2
System Common	Song Position Song Select Tune	× × ×	××××	
System Real Time	Clock Command	××	× ×	
Aux	Local On/Off All Notes Off Active Sense	00 ××	× × × × ×	*1

Mode 1: OMNI ON, POLY Mode 3: OMNI OFF, POLY Mode 2: OMNI ON, MONO Mode 4: OMNI OFF, MONO O:Yes X : No

Consult your local Korg distributor for more information on MIDI IMPLEMENTATION. MIDI Implementationの配布については、コルグお客様相談窓口へお問い合わせください。