

nanoPAD

MIDI Implementation Chart

Function		Transmitted	Recognized	Remarks
Basic Channel	Default	1 – 16	×	Memorized
	Changed	1 – 16	×	
Mode	Memorized Messages Altered	×	×	*1
		○ *****	×	
Note Number:	True Voice	0 – 127 *****	×	
Velocity	Note On	○ 1 – 127	×	
	Note Off	○ 64	×	
Aftertouch	Polyphonic (Key)	×	×	
	Monophonic (Channel)	×	×	
Pitch Bend		○	×	X-Y pad
Control Change	0 – 127	○	×	Trigger pads, X-Y pad
Program Change	Variable Range	×	×	
		*****	*****	
System Exclusive		○	○	*2
System Common	Song Position	×	×	
	Song Select	×	×	
	Tune	×	×	
System Real Time	Clock	×	×	
	Command	×	×	
Aux Messages	Local On/Off	○	×	*1
	All Notes Off	○	×	*1
	Active Sense	×	×	
	Reset	×	×	
Notes				
*1: Valid if assigned as a MIDI control change.				
*2: In addition to Korg exclusive messages, also responds to inquiry messages.				

Mode 1: OMNI ON, POLY

Mode 2: OMNI ON, MONO

○ : Yes

Mode 3: OMNI OFF, POLY

Mode 4: OMNI OFF, MONO

× : No

Consult your local Korg distributor for more information on MIDI IMPLEMENTATION.

MIDI Implementationの配布については、コルグお客様相談窓口へお問い合わせください。