

Grandstage 73/88

System Version 1.0.2

December 18, 2017

Changes Since Grandstage System Version 1.0.1

General

Changes

The USB Product ID has been updated. To connect the Grandstage to your Mac or Windows computer, please download and install the latest version of the KORG USB-MIDI driver. The driver is available from the Korg website: <http://www.korg.com>

Bug fixes

When using the soft pedal (for example, by assigning Soft(CC#87) to the Foot Switch), low velocity notes might have sounded incorrectly. This has now been fixed.

In Demo mode, the damper pedal might have become stuck in the “on” state. This has now been fixed.

Panel Operation

Improvements

Saving to USB storage devices has been improved. If the device is not valid—for instance, if it does not allow data to be written—failing at “Save .FAV File” will now display the “Save Error” message.

When editing Foot – Pedal / Switch MIDI Control Change assignments in SYSTEM mode, the system resets the MIDI Control Change values. This reset mechanism has been improved.

Bug fixes

In rare cases depending on specific timing, using the SYSTEM mode commands “Factory Reset” or “Save/Load .FAV File” might have caused an operational error. This has now been fixed.

In addition to those listed above, various other minor improvements and bug fixes are also included in this update.