

MIDI Implementation Chart

Function...		Transmitted USB-MIDI	Received	Remarks
Basic Channel	Default Change	1-16 1-16	1-16 1-16	Memorized
Mode	Default Messages Altered	X *****	3 X X	
Note Number	True Voice	48-84 *****	0-127 12-127	*1
Velocity	Note On Note Off	X 9n, v=64 X 8n, v=64	X 9n, V=1-127 X	
After Touch	Key's Channel	X X	X X	
Pitch Bend		X	O	
Control Change	120 121	X X	O O	All Sound Off Reset All Controllers *2
Program Change	True Number	X *****	X	
System Exclusive		O	O	*1, *3
System Common	Song Position Song Select Tune Request	X X X	X X X	
System Real Time	Clock Commands	X X	X X	
Aux Meassages	Local On/Off All Notes Off Active Sense System Reset	X X X X	X O 123-127 O X	

Notes

- *1: Transmitted only with a USB connection.
- *2: Treated as All Notes Off.
- *3: Support only Inquiry message.

Mode 1: Omni On, Poly
 Mode 3: Omni Off, Poly

Mode 2: Omni On, Mono
 Mode 4: Omni Off, Mono

O: Yes
 X: No

Consult your local Korg distributor for more information on MIDI implementation.