MIDI Implementation Chart

Date: Oct. 10. 2014				
Version: 1.00				

	_			
Function		Transmitted	Received	Remarks
Basic Channel	Default Change	1–16 1–16	1–16 1–16	Memorized
Mode	Default Messages Altered	X *******	3 X X	
Note Number	True Voice	48–84	0–127 12–127	*1
Velocity	Note On Note Off	X 9n, v=64 X 8n, v=64	X X	
After Touch	Key's Channel	X X	X X	
Pitch Bend		Х	Х	
Control Change	120	X	0	All sound off *2
Program Change	True Number	X *******	X *******	
System Exclusive		Х	Х	
System Common	Song Position Song Select Tune Request	X X X	X X X	
System Real Time	Clock Commands	X X	X X	
Aux Meassages	Local On/Off All Notes Off Active Sense System Reset	X X X	X O 123–127 O X	

Mode 1: Omni On, Poly Mode 3: Omni Off, Poly Mode 2: Omni On, Mono Mode 4: Omni Off, Mono O: Yes X: No

Notes
*1: Transmitted only with a USB connection.

^{*2:} Treated as All sound off.