

PCM Card + Prog/Comb Card    M1 / M1R / M1-EX / M1R-EX / T-ser.

Product No.	PCM Card No.	Title	PCM No.	Name
MSC-1S	MSC-01	Strings, etc.	C00	Strings
			C01	Saxophone
			C02	Marimba
			C03	Spring
			C04	Low Violin
			C05	Piano
			C06	Harp
C07	Chorus			
MSC-2S	MSC-02	SYNTH 1	C00	Bell Wave
			C01	Room Hit
			C02	Clang
			C03	Slap Hit
			C04	Wave PAD
			C05	Phase #1
			C06	MIDI Vox
			C07	E.Bass2
			C08	Syn.Bass3
			C09	Digital 6
			C10	M.Wave
			C11	Syn.Bass 4
			C12	S&H-Wave
			C13	Perc.Wave
			C14	Syn.Bass 5
			C15	Digital 7
C16	Oct.Wave			
MSC-3S	MSC-03	DRUMS 1	C00	Kick 4
			C01	Kick 5
			C02	Kick 6
			C03	Kick 7
			C04	Snare 5
			C05	Closed HH3
			C06	Pedal
C07	Open HH3			

C08	Ride 2
C09	Tom Tom
C10	Bang
C11	Crack
C12	Timbale3
C13	Mokugyo
C14	Tsuzumi
C15	O-Daiko
C16	Shimedaiko
C17	Tabla 1
C18	Tabla 2
C19	Tabla 3
C20	Tabla 4
C21	Hand SLP1
C22	Hand SLP2
C23	Stick 1
C24	Stick 2
C25	Stick 3
C26	Lo Bongo
C27	Hi Bongo

MSC-4S

MSC-04

ORCHESTRA 1

C00	Bassoon
C01	Clarinet
C02	Oboe
C03	F.Horn
C04	Strings2
C05	Strings3
C06	Bs/Cl/VI
C07	Harp
C08	Pipe Organ
C09	25% Pulse
C10	16% Pulse
C11	10% Pulse
C12	8% Pulse
C13	4% Pulse
C14	2% Pulse
C15	Digital 3
C16	Saw Wave 2
C17	DWGS Ramp
C18	DWGS Metal

MSC-5S

MSC-05

PIANO

C00	Piano
-----	-------

MSC-6S	MSC-06	FRETTED INSTS 1	C00	Rock Gt2
			C01	Clean Gtr
			C02	Jazz Gtr
			C03	Acc Gtr
			C04	Mutes
			C05	Banjo
			C06	KOTO
			C07	Santur
			C08	Slap Bass
			C09	Round Bass
			C10	Finger Bass
			C11	Sticker
			C12	Clav
			C13	Feedback
MSC-7S	MSC-07	SYNTH 2	C00	Wavesweep3
			C01	Wavesweep4
			C02	Res Wave 1
			C03	Res Wave 2
			C04	Mouthharp
			C05	Spectrum 1
			C06	Spectrum 2
			C07	Spectrum 3
			C08	Noise
			C09	Pulse Pad
			C10	Bellz
			C11	Chiff Bass
MSC-8S	MSC-08	PERCUSSION	C00	Anvil
			C01	Anvil NT
			C02	Fingercymb
			C03	Tine
			C04	Tine NT
			C05	Alarm
			C06	Vibraslap1
			C07	Vibraslap2
			C08	Gun Shot
			C09	Gun Shot NT
			C10	Cicada
			C11	Zaping
			C12	Buzzard

C13 Tube  
 C14 Guiro 1  
 C15 Guiro 2  
 C16 Guiro 2 NT  
 C17 Triangle  
 C18 Belltree  
 C19 Belltree NT  
 C20 Bang  
 C21 Shaker  
 C22 Shaker NT  
 C23 Claves  
 C24 10% Pulse  
 C25 25% Pulse  
 C26 Digital 3

MSC-9S MSC-09 ORGAN

C00 Super BX3  
 C01 Full Pipe  
 C02 Harmonium  
 C03 Analog Org  
 C04 Split Organ  
 C05 Perc2 2/3  
 C06 Full Organ  
 C07 Jazz 1  
 C08 Jazz 2

MSC-10S MSC-10 ETHNIC

C00 Shakuachi  
 C01 Steel Drum  
 C02 Thai Bell  
 C03 Dulcimer  
 C04 Bulroar  
 C05 Fing Cymbal  
 C06 Shellop  
 C07 Penny Whistl  
 C08 Rainmaker  
 C09 Ldumlat  
 C10 Fing Cym NT  
 C11 Shlloop NT  
 C12 Rainmkr NT  
 C13 Ldumalt NT  
 C14 Ldumalt 2 NT  
 C15 Ldumalt 3 NT

MSC-11S	MSC-11	BRASS	C00	Trp Brass
			C01	Alto Sax
			C02	Bari Sax
			C03	Soprano Sax
			C04	Frenchhorn
			C05	Mute TP
			C06	Trombone
MSC-12S	MSC-12	SYNTH 3	C00	Saw
			C01	Saw Oct
			C02	Square
			C03	Pulse Dual
			C04	High Pass
			C05	Sync
			C06	Whitenoise
			C07	Syn Brass
			C08	Syn Pad
			C09	Syn Bass 2
			C10	Syn Bass 3
C11	Perc Bell			
MSC-13S	MSC-13	ETHNIC 2	C00	Bouzouki
			C01	Gopichand
			C02	Tambura
			C03	Santur 2
			C04	Rubab
			C05	Esraj
			C06	Gamelan2
			C07	Side Bachi
			C08	Side Bachi NT
			C09	Hitiriki
			C10	Shamisen
			C11	Biwa
			C12	Koto 2
C13	Shou			
MSC-14S	MSC-14	SOUND EFFECTS	C00	Rain Leak
			C01	Rain Leak NT
			C02	Rats!
			C03	Toy Cyclor
			C04	Toy Cyclor NT
C05	Tap-Tap			

C06 Zigzag  
 C07 Dragon Lore  
 C08 Dragon NT 1  
 C09 Dragon NT 2  
 C10 Dragon NT 3  
 C11 Factory  
 C12 Factory NT  
 C13 Coin Spin  
 C14 Coin Spin NT  
 C15 Shake Box  
 C16 Quick  
 C17 Pop Comp  
 C18 Pop Comp NT1  
 C19 Pop Comp NT2  
 C20 Pop Comp NT3  
 C21 Pop Comp NT4  
 C22 Peel Off  
 C23 Razor Edge

MSC-15S      MSC-15      DRUMS 2

C00 Metal BD  
 C01 Rock BD  
 C02 Jazz BD  
 C03 Megal SD  
 C04 Rock SD  
 C05 Jazz SD  
 C06 Closed HH  
 C07 Open HH  
 C08 Clash  
 C09 Ride  
 C10 Low Tom  
 C11 Mid Tom  
 C12 Hi Tom

MSC-16S      MSC-16      ENVIRONMENT

C00 Air Hammer  
 C01 Air Hammer NT  
 C02 Industry  
 C03 Industry NT  
 C04 Shinjuku  
 C05 Shinjuku NT  
 C06 Wind 01  
 C07 Wind 01 NT  
 C08 Wind 02

C09	Wind 02 NT
C10	Water
C11	Water NT
C12	Frog
C13	Frog NT
C14	Autumn
C15	Autumn NT
C16	Horse
C17	Horse NT